













 **Hotpoint**







**EN    Operating Instructions**









SG C11 CKG UK









**E****F****G****H**

**OFF**  
10'

**I****J**

**K**



## GENERAL SAFETY INSTRUCTIONS

- If the plug, power cord or appliance appear to be damaged or if any visible damage or water leaks are found, do not operate the iron. In such cases have it checked by Hotpoint's authorised staff in order to avoid any hazardous situation.
- If the appliance was dropped, do not operate it.
- This appliance can be used by children aged from 8 years and above and persons with reduced physical, sensory or mental capabilities or lack of experience and knowledge if they have been given supervision or instruction concerning use of the appliance in a safe way and understand the hazards involved.
- Supervise children to prevent them from playing with the appliance.
- Never leave the appliance unattended when it is plugged into an electrical socket.
- After each use of the appliance and when filling the water reservoir, place the appliance in a stable position and disconnect the plug from the electrical socket.
- The appliance must be used and placed on a stable flat horizontal surface. We recommend using an ironing board.
- For your safety, all repairs or maintenance operations on the appliance must be carried out exclusively by Hotpoint's authorised staff.
- Cleaning and user maintenance shall not be made by children without supervision.
- Keep the iron and its cord out of reach of children less than 8 years of age when it is energized or cooling down.



**This symbol warns operators that surfaces are liable to get hot during use and can burn your skin.**

## DESCRIPTION OF THE APPLIANCE

1. Power cord holder
2. Temperature indicator light
3. Iron
4. Soleplate
5. Iron supporting base
6. Boiler
7. Boiler closing cap
8. Water reservoir
9. Cord-rewinding clip
10. Electric power cord
11. Steam cable
12. Steam button
13. Continuous steam button
14. No-water indicator light
15. On/Off knob
16. Steam Ready indicator light
17. On indicator light
18. Filter
19. Temperature control

- This product is intended only for ironing of clothing and household laundry.
- Only connect the appliance to a grounded socket. When using an extension cord, make sure that a grounded socket is available.
- Regularly check the condition of the power cord.
- When cleaning the appliance, make sure it has been unplugged from the socket.
- Disconnect the plug from the socket by holding the plug and not by pulling the cable.
- Prevent the power cord and steam cable from touching the hot soleplate. Use the special cord-rewinding clip.



**The iron soleplate and the water / steam coming out of the soleplate are very hot and can burn your skin.**

- Before storing the steam generator, wait until it has completely cooled down - it will take about three hours.
- Do not direct steam towards people or animals and do not iron garments while worn.
- Never add any perfume, vinegar, starch, scale-removing agents, ironing products or other chemicals in the water reservoir - unless recommended by Hotpoint. Never use contaminated water.
- Never immerse the appliance in water or any other liquid.
- Do not leave the appliance in the open air and exposed to inclement weather conditions.
- Never leave or use the appliance over or close to flames, ovens, flammable materials or other sources of heat.

## INTRODUCTION

**Welcome to Hotpoint's Garment Care. Thank you for purchasing our new steam generator. We recommend registering this product on [www.hotpoint.co.uk](http://www.hotpoint.co.uk) to make sure you are entitled to all the benefits made available by Hotpoint's Customer Service.**

This appliance was developed for household use only and is not intended for industrial use.



**Before you begin using the appliance, it is important that you thoroughly read these instructions and carefully keep them for further reference.**

## GENERAL SAFETY RULES

The safety features of your steam generator comply with the technical specifications and regulations in force.



**The voltage of your system must match the voltage of the steam generator (220-240 V). Any connection error could cause irreversible damage to the steam generator and void its warranty.**

- Use the appliance only for its intended use as described in this manual.



**When being used, the boiler can get very hot. Wait until the steam generator has completely cooled down before putting it away.**

- Should you suspect a failure, immediately unplug it from the electrical socket.
- The manufacturer shall assume no responsibility in case of damage resulting from any improper use of the appliance.

## Replacing the fuse

When replacing a faulty fuse, a 13 amp ASTA approved fuse to BS 1362 should always be used, and the fuse cover re-fitted. If the fuse cover is lost, the plug must not be used until a replacement is obtained.

## Replacement fuse covers

If a replacement fuse cover is fitted, it must be of the correct colour as indicated by the coloured marking or the colour that is embossed in words on the base of the plug. Replacements can be obtained directly from your nearest Service Depot.

## Removing the plug

If your appliance has a non-rewireable moulded plug and you should wish to re-route the mains cable through partitions, units etc., please ensure that either:

- the plug is replaced by a fused 13 ampere rewireable plug bearing the BSI mark of approval.
- or:
- the mains cable is wired directly into a 13 amp cable outlet, controlled by a switch, (in compliance with BS 5733) which is accessible without moving the appliance.

## Disposing of the plug

Ensure that before disposing of the plug itself, you make the pins unusable so that it cannot be accidentally inserted into a socket.

## Instructions for connecting cable to an alternative plug

 **The wires in the mains lead are coloured in accordance with the following code:**

<b>GREEN &amp; YELLOW</b>	<b>EARTH</b>
<b>BLUE</b>	<b>NEUTRAL</b>
<b>BROWN</b>	<b>LIVE</b>

As the colours of the wires in the lead may not correspond with the coloured markings identifying the terminals in your plug, proceed as follows:


- Connect Green & Yellow wire to terminal marked **E** or  or coloured Green or Green & Yellow.
- Connect Brown wire to terminal marked **L** or coloured Red.
- Connect Blue wire to terminal marked **N** or coloured Black.

If a 13 amp plug (BS 1363) is used it must be fitted with a 13 amp fuse, either in the plug or adaptor or at the distribution board.

If you are in any doubt regarding the electrical supply to your machine, consult a qualified electrician before use.

## How to connect an alternative plug

The wires in this mains lead are coloured in accordance with the following code:



-  **The power supply cable must never be bent or dangerously compressed.**
-  **The power supply cable must only be replaced by an authorised serviceman.**

## BEFORE USE

Before using the iron for the first time, remove all stickers, protective plastic or cardboard packaging from the soleplate of the iron.

Make sure that all adhesive parts have been removed from the soleplate using a damp soft cloth and remove any residues or particles from the manufacturing process by repeatedly filling and emptying the water reservoir.

 **When you switch on the iron for the first time, you may notice an unpleasant smell, a little smoke and some impurities. They will disappear in a few minutes. When using the steam function for the first time, do not direct the steam jet on the garments because manufacturing residues may be present in the steam dispenser.**

 **Never add any perfume, vinegar, starch, scale-removing agents, ironing products or other chemicals in the water reservoir - unless recommended by Hotpoint. Never use contaminated water or coming from driers, accumulators or air conditioners.**

## FILLING THE WATER RESERVOIR

Water plays an essential role both in the ironing process and in the good operation of the appliance over a long lifespan. In particular, a high concentration

of limescale may damage some parts of the iron and cause its early deterioration.

The iron water tank has a capacity of 1200ml with extra 200ml boiler.

### Suitable water

Although the iron with steam generator can be used with tap water, if the water is very hard (as measured in French degrees), we recommend mixing tap water and demineralised water according to the following table.

Hardness degree [°f]	Proportion [tap water:demineralised water]
7°f	1:0
7°f - 14°f	1:0,5
14°f - 22°f	1:1
22°f - 32°f	1:2
32°f - 54°f	1:3
>54°f	0:1

To determine the hardness degree of the water in your area, contact your local water board or body. This data is sometimes available on the board/body's website too.

### Filling the water reservoir (A)

Before every use and every time the no-water indicator light turns on, fill the water reservoir:

1. Use the special handle to remove the water reservoir (8).
2. When filling the reservoir, make sure the maximum level shown on the reservoir is not exceeded.
3. Re-place the water reservoir in the relevant housing until it clicks into place.
4. Repeat the operation every time the water-level indicator light (14) turns on.

 **Never add any perfume, vinegar, starch, scale-removing agents, ironing products or other chemicals in the water reservoir - unless recommended by Hotpoint. Never use contaminated water.**

## USING YOUR IRON

### Temperature selection and steam adjustment (B)

1. Connect the plug of the appliance to a grounded socket (220/240V).
2. Turn the ON/OFF knob (15) so that the ON light will light up to show that the steam generator is ON.
3. Wait until the temperature indicator on the iron light turns off before starting ironing.
4. Select the appropriate steam setting by means of the ON/OFF knob (15) in position  to iron with steam or in position  to iron without steam. As soon as the selected steam quantity is available, the Steam Ready indicator light (16) will turn on.

 **Fabrics with this symbol on the label must not be ironed.**

GARMENT LABEL	FABRIC TYPE	TEMPERATURE INDICATION	STEAM INDICATION
	synthetic		Min
	silk mixed cotton		Min
	wool mixed wool		
	cotton		
	linen jeans		

## USING THE APPLIANCE

 **When you switch on the steam generator for the first time, you may notice an unpleasant smell, a little smoke and some impurities. They will disappear in a few minutes.**

### Ironing without steam (C)

1. Set the ON/OFF knob (15) to the  position (= no steam).
2. Select the recommended ironing temperature using the temperature control (19) - (see step
3. B, chapter "Temperature selection and steam adjustment").

## Ironing with steam (D)

1. Make sure that the water level in the reservoir is higher than 1/4.
2. Set the ON/OFF knob in  position.
3. Select the recommended ironing temperature by using the temperature selector (19) (see step B, chapter "Temperature selection")
4. Press the steam button (12) to use the steam ironing function. We recommend using the steam button function when the temperature is higher than. ● ● ● .

 **Wait for the temperature indicator light to turn off and for the Steam Ready indicator light to turn on, before pressing the steam button.**

## Ironing with continuous steam (E)

The continuous steam function is useful to iron out any persistent wrinkles through a uniform emission of steam onto the fabrics.

1. Make sure that the water level in the reservoir is higher than 1/4.
2. Select the recommended ironing temperature using the temperature control (19) - see step B, chapter "Temperature selection".
3. Press the continuous steam button (13) and activate the slider on the button in order to get a continuous steam flow when ironing. We recommend using the continuous steam button when the temperature is higher than ● ● ● .

 **Wait for the temperature indicator light to turn off and for the Steam Ready indicator light to turn on, before pressing the steam button.**

## FEATURES

### Vertical steam function (F)

The vertical steam function is useful to iron out wrinkles from hanging garments, curtains etc. To use this function just place your iron in a vertical position. All the functions of the steam generator will remain unchanged in this position - refer to paragraph "Using the appliance".

 **Do not direct steam towards people or animals and do not iron garments while worn.**

## Eco function (G)

Your generator is equipped with an Eco function that allows energy savings of energy and water compared to normal consumption in terms of maximum steam level. To start the Eco function set the ON/OFF knob (15) to .

## Automatic switch-off function (H)

The automatic switch-off function ensures total safety. This function automatically switches off the steam generator when it is not used for a few minutes. In particular, your steam generator will automatically switch off after 10 minutes if it is left unused.

If you leave the steam generator unattended, a buzzer will sound to inform you that the automatic switch-off function is active. To restart it, just press the ON/OFF button.

 **Wait for the Steam Ready indicator light to turn on again and for the temperature indicator light to turn off before start ironing again.**

## CLEANING AND MAINTENANCE

### After use (I)

1. Disconnect the appliance plug from the electrical socket and let the steam generator cool down.
2. Empty the water reservoir (8).
3. Wind the steam cable (11) and the power-supply cord (10) around the special cord-rewinding clip (9).
4. Store the steam generator in a safe dry place.
5. Let the steam generator cool down and store it in a safe dry place.

### Cleaning (J)

 **Never use aggressive and/or abrasive products to clean the plastic parts and the iron soleplate.**

1. Disconnect the appliance plug from the electrical socket and let the steam generator cool down.
2. Clean the plastic parts of the steam generator with a soft damp cloth and dry.
3. For routine cleaning and/or the removal of stains or other residues deposited on the plate, use a damp soft cloth and dry.
4. Use a damp cotton tip to remove any scale in the steam holes that may impair the performance of your steam generator.

 In order to keep the soleplate perfectly smooth and polished, avoid any contact with metal objects and do not iron sharp objects such as buttons, studs and hinges - they may scratch the plate.

5. Regularly rinse the water reservoir (8) under clean water. After cleaning, always empty the water reservoir.

## Scale removal (K)

Your steam generator is equipped with the descaling system (18). If the anti-scale cartridge is not in position the device will not produce steam. Please replace the anti-scale cartridge every three months of use (average use = 2,5 hours / week).

To replace the cartridge please extract it from its slot inside the water tank and replace it with a new one.

 **The descaling filter does not purify water from impurities other than limescale. We recommend to check that mains water is not contaminated by these impurities that could affect the performance your steam generator.**

 **If you wish to clean it the boiler of your steam generator, please wait at least 3 hours until the steam generator has completely cooled down.**

1. Make sure the appliance is disconnected from the electrical socket.

 **Clean it near a sink and away from fabrics so that they don't get stained.**

2. Remove the water reservoir (8) and place the steam generator on a steady flat surface.
3. Turn the steam generator upside down. Unscrew the boiler closing cap (7)
4. Empty the boiler of any residual water.
5. Fill the boiler with 500 ml of water. Then close, shake the steam generator and empty it. Repeat the operation at least twice.
6. Close the boiler, making sure its closing cap has been fastened all the way.
7. Re-place the boiler in its ordinary usage position.
8. Connect the appliance to a socket and turn again the ON/OFF knob to start using again your steam generator with boiler.

 **When you start the steam generator again, before using the steam function on the**

**garments press the steam button for at least one minute to eject any residues or particles that could stain the fabrics.**

## HINTS

If your steam generator is equipped with the Optimal Soleplate Temperature technology, you need not adjust the temperature and/or steam. You can iron all the types of fabrics that can be ironed in any order.

- Sort the garments out according to the fabric types. This will reduce the need to adjust the temperature according to the different fabrics.
- Start with the garments that require a low ironing temperature and continue with the garments requiring higher ironing temperatures.
- If you are not sure about the composition of the fabric, try ironing a hidden part such as a seam, hem or internal section. Start with low temperature and gradually increase it until you find the ideal ironing setting.
- When you reduce the steam generator's temperature to iron delicate garments, wait approximately 2 minutes to let the steam generator reach the new settings.
- Pure wool (100% wool) garments can be steam-ironed as long as the temperature is set to wool. We recommend using a cotton cloth to prevent any shiny marks on the garment.
- Never iron areas with obvious perspiration marks because the heat will make the stains fast and permanent.

## GUARANTEE

**12 months Standard Guarantee  
Enhanced to 2 years upon product registration**

This certificate of guarantee represents the guarantee ("Guarantee" hereinafter) offered by Indesit Company UK Limited with registered office at Peterborough PE2 9JB in relation to products purchased in the United Kingdom and Indesit Ireland Limited with registered office in Dublin 9, Ireland for products purchased in the Republic of Ireland. This Guarantee does not affect your statutory rights.

Your product has the benefit of our manufacturer's Guarantee, which covers the product for twelve months from the date of purchase.

This gives you the reassurance that if, within that time, your product is proven to be defective because of either workmanship or materials, we will, at our discretion, either repair or replace the product at no cost to you.

This Guarantee is subject to the following conditions:

- Documentary proof of original purchase date is provided.

- Cosmetic damage must be reported within 14 days from the date of purchase.
- The product has been installed and operated correctly and in accordance with our operating and maintenance instructions.
- The product is used only on the electricity supply printed on the rating plate.
- The product has been used for normal domestic purposes only.
- The product has not been altered, serviced, maintained, dismantled, or otherwise interfered with by any person not authorised by us.
- Any repair work must be undertaken by us or our appointed agent.
- Any parts removed during repair work or any product that is replaced become our property.
- The product is used in the United Kingdom or Republic of Ireland.

The Guarantee does not cover:

- Damage resulting from transportation, improper use, neglect or interference or as a result of improper installation.
- Accidental damage, this includes but is not limited to, damage which occurs as a result of an external action.
- Replacement of any consumable item or accessory. These include but are not limited to:
  - plugs, cables, light bulbs, hoses, brushes, covers and filters.
  - Replacement of any removable parts made of glass or plastic.

## After Sales Service

No one is better placed to care for your Hotpoint product during the course of its working life than us – the manufacturer.

## Essential Contact Information Advice Line

We have a dedicated team who can provide free advice and assistance with your product if you experience any technical difficulties. Simply call our Hotpoint Service Hotline for telephone assistance.

**UK: 03448 240 055**

**Republic of Ireland 0818 904 041**

**[www.hotpointservice.co.uk](http://www.hotpointservice.co.uk)**

**Please note:**

**Our advisors will require the following information:**

Model number:

Serial number:

## Consumables and Accessories

We supply a full range of consumables and accessories to keep your product functioning efficiently throughout its life.

**UK: 03448 225 225**

**Republic of Ireland: 0818 313 413**  
**[parts.hotpoint.co.uk/shop](http://parts.hotpoint.co.uk/shop)**

## Recycling and Disposal Information

As part of Hotpoint's continued commitment to helping the environment, Hotpoint reserves the right to use quality, recycled components to keep down customer costs and minimise material wastage.

Please dispose of packaging and old products carefully.

### Register your new product and receive 1 additional year FREE!

As an additional benefit of owning your Hotpoint product, we are offering 1 years additional free guarantee. To be eligible for this you will need to contact us to register your product within 28 days of purchase. If you do not register your appliance within the 28 days you will still be entitled to 1 years manufacturer's guarantee. To activate your 2 year guarantee register online at [www.hotpoint.co.uk](http://www.hotpoint.co.uk). Please note that the extended guarantee is only available in the UK and Ireland and is subject to the same terms and conditions as the 1 year guarantee. Please refer to the certificate of guarantee for more information.

## DISPOSAL OF OLD ELECTRICAL APPLIANCES



The European Directive 2012/19/UE on Waste Electrical and Electronic Equipment (WEEE), requires that old household electrical appliances must not be disposed of in the normal unsorted municipal waste stream.

Old appliances must be collected separately in order to optimise the recovery and recycling of the materials they contain and reduce the impact on human health and the environment.



The crossed out "wheeled bin" symbol on the product reminds you of your obligation, that when you dispose of the appliance it must be separately collected. Consumers should contact their local authority or retailer for information concerning the correct disposal of their old appliance.



## TROUBLESHOOTING

### Problem

### Possible causes / Solutions

The soleplate stays cold and does not warm up.

- The plug was not inserted or is not making contact.
- Make sure the temperature is not set to Min.

The temperature indicator light goes on and off.

- The temperature indicator light is on. This shows that the iron is warming up. The indicator light will turn off when the set temperature is reached.

Steam comes out in a reduced quantity or does not come out at all.

- Not enough water in the water reservoir. Fill up the water reservoir.
- The iron is not hot enough. Place the iron on the special supporting base and wait until the temperature indicator light turns off before you start ironing.
- The plate temperature may be too low because the steam button has been activated too frequently. Slightly increase the time interval between steam shots.
- Make sure the ON/OFF knob is not set to .

Impurities coming out of the soleplate could stain the garments.

- There may be residues in the vaporisation chamber. Clean it as shown in the chapter "Cleaning and maintenance" under paragraph "Descaling".
- You are using perfume, vinegar, starch, scale-removing agents, ironing products or other chemicals. Remember that these substances may damage the product. Rinse the water reservoir.
- You are not using the correct water type. Rinse the water reservoir and add tap water only. In case of very hard water, we recommend mixing it proportionally with demineralised water - see chapter "Filling the water reservoir".
- You are using starch. You can use starch directly on the reverse side of the fabrics and in any case never in the water reservoir.
- The garment was not washed correctly or it has some soap residues.
- You are ironing a new garment not yet washed for the first time.

Water is dripping out of the soleplate.

- The plate temperature may be too low because the steam button has been activated too frequently. Slightly increase the time interval between steam shots.
- The soleplate temperature is set to a temperature that is too low.
- You used the steam function at a temperature that was too low. We recommend using these functions at temperatures higher than ●●●.

The soleplate is dirty or dark and may stain the fabrics.

- You are using a temperature that is too high.
- Clean the soleplate - see chapter "Cleaning and maintenance" under paragraph "Cleaning".
- You are using starch. You can use starch directly on the reverse side of the fabrics and in any case never in the water reservoir.
- The garment was not washed correctly or has some soap residues.
- You are ironing a new garment not yet washed for the first time.

**The no-water indicator light is on.**

- The water reservoir needs filling.
- The water reservoir was not fitted correctly. Place the water reservoir in the relevant housing until it clicks into place.

**The Steam Ready indicator light turns on and off.**

- The Steam Ready indicator light turns on to show that the steam generator has reached the desired steam settings. When you use the steam function, the indicator light turns off. It turns on again when such settings are reached again.



Indesit Company UK Ltd  
Morley Way,  
Peterborough PE2 9JB

[www.indesitcompany.com](http://www.indesitcompany.com)

Power Perfection  
03/2015 - ver. 3.0