

**GB**

English, 1

**RZ 1066 B**

### Contents

**GB**

#### **Installation, 2-3-4-5**

Unpacking and levelling  
Connecting the electricity and water supplies  
The first wash cycle  
Technical data

#### **Care and maintenance, 6**

Cutting off the water or electricity supply  
Cleaning the detergent dispenser drawer  
Cleaning the pump  
Cleaning the washing machine  
Descaling Cycle  
Caring for the door and drum of your appliance  
Checking the water inlet hose

#### **Precautions and tips, 7**

General safety  
Disposal

#### **Description of the washing machine, 8-9**

Control panel  
Display

#### **Running a wash cycle, 10**

#### **Wash cycles and functions, 11**

Table of wash cycles  
Available options

#### **Services, 12-13**

#### **Detergents and laundry, 14**

Detergent dispenser drawer  
Preparing the laundry  
Special wash cycles  
Load balancing system

#### **Troubleshooting, 15-16**

#### **Product Guarantee and Repair Information, 17**

# Installation


GB

! Keep this instruction manual in a safe place for future reference. Should the appliance be sold, transferred or moved, make sure the instruction manual accompanies the washing machine to inform the new owner as to its operation and features.

! Read these instructions carefully: they contain vital information on installation, use and safety.


## Unpacking and levelling

### Unpacking



! This is a separate part of the polystyrene base and should be removed with the base.

! **IMPORTANT** check when unpacking your machine.




1. Unpack the washing machine.
2. Check whether the washing machine has been damaged during transport. If this is the case, do not install it and contact your retailer.
3. Remove the 4 protective screws and the rubber bush with the respective spacer, situated on the rear of the appliance (see also the installation leaflet).

4. Seal the gaps using the plastic plugs provided.  
5. Keep all the parts: you will need them again if the washing machine needs to be moved to another location.

! Packaging materials are not children's toys.

### Levelling

Your machine may make a considerable amount of noise if the two front feet have not been adjusted correctly.




1. Install the washing machine on a flat sturdy floor, without resting it up against walls, cabinets or anything else.

2. If the floor is not perfectly level, compensate for any unevenness by tightening or loosening the adjustable front feet (see figure); the angle of inclination, measured according to the worktop, must not exceed 2°.

Levelling your appliance correctly will provide it with stability and avoid any vibrations, noise and shifting during operation. If it is placed on a fitted or loose carpet, adjust the feet in such a way as to allow enough room for ventilation beneath the washing machine.


## Electric and water connections

### Connecting the water inlet hose



1. Connect the supply pipe by screwing it to a cold water tap using a 3/4 gas threaded connection (see figure).

Before performing the connection, allow the water to run freely until it is perfectly clear.



2. Connect the other end of the water inlet hose to the washing machine, screwing it onto the appliance's cold water inlet, situated on the top right-hand side on the rear of the appliance (see figure).

3. Make sure there are no kinks or bends in the hose.


! The water pressure at the tap must be within the values indicated in the Technical details table (on the page 5).

! If the water inlet hose is not long enough, contact a specialist store or an authorised serviceman.


! Ensure that the supply taps are allowing water through. Old taps may seize in the closed position and thus prevent water reaching the machine.

! Never use second-hand or old inlet hoses; use the products supplied with the machine.


## Connecting the drain hose



Connect the drain hose, without bending it, to a draining duct or a wall drain situated between 65 and 100 cm from the floor;



The drain hose may be connected to an under-sink trap. Before connecting the drain hose from the machine ensure that any blanks or removable ends have been taken off the spigot.



If it is placed over the edge of a basin or sink be sure the free end of the hose should not be under-water.

**!** We advise against the use of hose extensions; in case of absolute need, the extension must have the same diameter as the original hose and must not exceed 150 cm in length. Ensure that if the drain hose is pushed into a standpipe, that the end does not go down more than 15cms (6 inches). If the hose is pushed down too far, this may cause the machine to self-siphon ie. continuously empty as it is filling.

## Electric connection

Before plugging the appliance into the mains socket, make sure that:

- the socket is earthed and in compliance with the applicable law;
- the socket is able to sustain the appliance's maximum power load indicated on the Technical Data Plate fixed on the machine;

- the supply voltage is included within the values indicated on the Technical Data Plate fixed on the machine.
- the socket is compatible with the washing machine's plug. If this is not the case, replace the socket or the plug.

Your appliance is now supplied with a 13 amp fused plug it can be plugged into a 13 amp socket for immediate use. Before using the appliance please read the instructions below.

**WARNING - THIS APPLIANCE MUST BE EARTHED.**  
THE FOLLOWING OPERATIONS SHOULD BE CARRIED OUT BY A QUALIFIED ELECTRICIAN.

### Replacing the fuse:

When replacing a faulty fuse, a 13 amp ASTA approved fuse to BS 1362 should always be used, and the fuse cover re-fitted. If the fuse cover is lost, the plug must not be used until a replacement is obtained.

### Replacement fuse covers:

If a replacement fuse cover is fitted, it must be of the correct colour as indicated by the coloured marking or the colour that is embossed in words on the base of the plug. Replacements can be obtained directly from your nearest Service Depot.

### Removing the plug:

If your appliance has a non-rewireable moulded plug and you should wish to re-route the mains cable through partitions, units etc., please ensure that either:  
the plug is replaced by a fused 13 ampere rewireable plug bearing the BSI mark of approval.

or:

the mains cable is wired directly into a 13 amp cable outlet, controlled by a switch, (in compliance with BS 5733) which is accessible without moving the appliance.

### Disposing of the plug:

Ensure that before disposing of the plug itself, you make the pins unusable so that it cannot be accidentally inserted into a socket.

Instructions for connecting cable to an alternative plug:

Important: the wires in the mains lead are coloured in accordance with the following code:

<b>Green &amp; Yellow</b>	<b>Earth</b>
<b>Blue</b>	<b>Neutral</b>
<b>Brown</b>	<b>Live</b>

As the colours of the wires in the lead may not correspond with the coloured markings identifying the terminals in your plug, proceed as follows:

Connect Green & Yellow wire to terminal marked **E** or  $\equiv$  or coloured Green or Green & Yellow.

Connect Brown wire to terminal marked **L** or coloured Red.

Connect Blue wire to terminal marked **N** or coloured Black.

If a 13 amp plug (BS 1363) is used it must be fitted with a


13 amp fuse, either in the plug or adaptor or at the distribution board.

If you are in any doubt regarding the electrical supply to your machine, consult a qualified electrician before use.

How to connect an alternative plug:

The wires in this mains lead are coloured in accordance with the following code:

<b>BLUE</b>	<b>NEUTRAL (N)</b>
<b>BROWN</b>	<b>LIVE (L)</b>
<b>GREEN &amp; YELLOW</b>	<b>EARTH (E)</b>



*Disposing of the appliance:*

When disposing of the appliance please remove the plug by cutting the mains cable as close as possible to the plug body and dispose of it as described on the previous page.

! The washing machine should not be installed in an outdoor environment, not even where the area is sheltered, because it may be very dangerous to leave it exposed to damp, rain and thunderstorms.

! When the washing machine is installed, the mains socket must be within easy reach.

! Do not use extensions or multiple sockets.

! The power supply cable must never be bent or dangerously compressed.

! The power supply cable must only be replaced by an authorised serviceman.

Warning! The company denies all liability if and when these norms are not respected.

**The first wash cycle**

Once the appliance has been installed, and before you use it for the first time, run a wash cycle with detergent and no laundry, using wash cycle number auto clean (see "Care and maintenance").

<b>Technical data</b>	
<b>Model</b>	RZ 1066 B
<b>Dimensions</b>	width 59.5 cm height 85 cm depth 60,5 cm
<b>Capacity</b>	from 1 to 10 kg
<b>Electrical connections</b>	please refer to the technical data plate fixed to the machine
<b>Water connections</b>	maximum pressure 1 MPa (10 bar) minimum pressure 0.05 MPa (0.5 bar) drum capacity 71 litres
<b>Spin speed</b>	up to 1600 rotations per minute
<b>Test wash cycles in accordance with regulations 1061/2010 1015/2010</b>	Eco Cotton 60°C. Eco Cotton 40°C.
	<p>This appliance conforms to the following EC Directives:</p> <ul style="list-style-type: none"> <li>- 2004/108/EC (Electromagnetic Compatibility)</li> <li>- 2006/95/EC (Low Voltage)</li> <li>- 2012/19/EU (WEEE)</li> </ul>


# Care and maintenance

GB

## Cutting off the water and electricity supplies

- Turn off the water tap after every wash cycle. This will limit wear on the hydraulic system inside the washing machine and help to prevent leaks.
- Unplug the washing machine when cleaning it and during all maintenance work.

## Cleaning the detergent dispenser drawer




Remove the dispenser by raising it and pulling it out (see figure). Wash it under running water; this operation should be repeated frequently.

## Cleaning the pump


The washing machine is fitted with a auto-clean pump which does not require any maintenance. Sometimes, small items (such as coins or buttons) may fall into the pre-chamber which protects the pump, situated in its bottom part.

! Make sure the wash cycle has finished and unplug the appliance.

To access the pre-chamber:



1. using a screwdriver, remove the cover panel on the lower front part of the washing machine (see figure);



2. unscrew the lid by rotating it anti-clockwise (see figure); a little water may trickle out. This is perfectly normal;  
3. clean the inside thoroughly;

4. screw the lid back on;  
5. reposition the panel, making sure the hooks are securely in place before you push it onto the appliance.

## Cleaning the washing machine

- The outer parts and rubber components of the appliance can be cleaned using a soft cloth soaked in lukewarm soapy water. Do not use solvents or abrasives.
- The washing machine has a Auto-Clean programme for its internal parts that **must be run with no load in the drum.**

To help the wash cycle you may want to use either the detergent (i.e. a quantity 10% the quantity specified for lightly-soiled garments) or special additives to clean the washing machine. We recommend running a cleaning programme every 40 wash cycles.

It can be activated in the following two ways:

- press the  button on the control panel then press the SELECTOR twice.
- turn the SELECTOR until it is on the  icon of the SERVICES menu, press it to enter the sub-menu, then turn it until it is on the  icon and press it two times.

## Descaling Cycle

A message on the display will remind the user to periodically run the descaling treatment, using a special detergent.

In order to identify the most suitable descaling product for your washing machine (WPRO), access [wpro.eu](http://wpro.eu).

The descaling cycle allows for keeping the machine's components (drum, pipes) clean. Whenever necessary, the display will visualise the following notice: "Descaling cycle recommended. Remind me later?"  / .

If the question is answered affirmatively, the message will appear at the end of the cycle or when the machine is switched on the next time. In case of a negative answer, the message will not reappear for the successive 100 cycles (the counter is reset).

For information on how to run the cycle, follow the instructions appearing on the package of the descaling product.

## Caring for the door and drum of your appliance

- Always leave the porthole door ajar in order to prevent unpleasant odours from forming.

## Checking the water inlet hose

Check the inlet hose at least once a year. If there are any cracks, it should be replaced immediately: during the wash cycles, water pressure is very strong and a cracked hose could easily split open.

! Never use second-hand hoses.

! This washing machine was designed and constructed in accordance with international safety regulations. The following information is provided for safety reasons and must therefore be read carefully.

## General safety

- This appliance was designed for domestic use only.
- This appliance can be used by children aged from 8 years and above and persons with reduced physical, sensory or mental capabilities or lack of experience and knowledge if they have been given supervision or instruction concerning use of the appliance in a safe way and understand the hazards involved. Children shall not play with the appliance. Cleaning and user maintenance shall not be made by children without supervision.
- Do not touch the machine when barefoot or with wet or damp hands or feet.
- Do not pull on the power supply cable when unplugging the appliance from the electricity socket. Hold the plug and pull.
- Do not open the detergent dispenser drawer while the machine is in operation.
- Do not touch the drained water as it may reach extremely high temperatures.
- Never force the porthole door. This could damage the safety lock mechanism designed to prevent accidental opening.
- If the appliance breaks down, do not under any circumstances access the internal mechanisms in an attempt to repair it yourself.
- Always keep children well away from the appliance while it is operating.
- The door can become quite hot during the wash cycle.
- If the appliance has to be moved, work in a group of two or three people and handle it with the utmost care. Never try to do this alone, because the appliance is very heavy.
- Before loading laundry into the washing machine, make sure the drum is empty.


## Disposal

- Disposing of the packaging materials: observe local regulations so that the packaging may be re-used.
- The European Directive 2012/19/EU on Waste Electrical and Electronic Equipment, requires that old household electrical appliances must not be disposed of in the normal unsorted municipal waste stream. Old appliances must be collected separately in order to optimise the recovery and recycling of the materials they contain and reduce the impact on human health and the environment. The crossed out "wheeled bin" symbol on the product reminds you of your obligation, that when you dispose of the appliance it must be separately collected. Consumers should contact their local authority or retailer for information concerning the correct disposal of their old appliance.

# Description of the washing machine

GB

## Control panel



**Detergent dispenser drawer:** used to dispense detergents and washing additives (see “Detergents and laundry”).

**ON/OFF button** : press this briefly to switch the machine on or off. To switch off the washing machine during the wash cycle, press and hold the button for approximately 3 seconds; if the button is pressed briefly or accidentally the machine will not switch off. If the machine is switched off during a wash cycle, this wash cycle will be cancelled.

**SELECTOR:** turn right or left to browse the different menu items on the display and select the wash cycles and services/functions desired; press to confirm the selection.

**BACK button:** returns you to the previous browsing level.

**DRIVE ME:** allows you to access the cycle guided selection section.

**STATISTICS button:** allows you to access the statistics section.

**AUTO-CLEAN button:** press to clean the machine’s internal parts (see “Care and maintenance”).

**DIRECT INJECTION button:** press to select the DIRECT INJECTION option.

**START/PAUSE button with indicator light:** when the green indicator light flashes slowly, press the button to start a wash cycle. Once the cycle has started the indicator light will remain lit in a fixed manner. To pause the wash cycle, press the button again; the indicator light will flash in an orange colour. If the symbol  is not illuminated, the door may be opened. To start the wash cycle from the point at which it was interrupted, press the button again.

### Standby mode

This washing machine, in compliance with new energy saving regulations, is fitted with an automatic standby system which is enabled after about 30 minutes if no activity is detected. Press the ON-OFF button briefly and wait for the machine to start up again.

### Antimicrobial seal

The seal around the porthole door is made from a special mixture ensuring antimicrobial protection, thus reducing bacterial proliferation up to 99.99%.

The seal contains zinc pyrithione, a biocidal substance which reduces the proliferation of harmful microbes (\*) such as bacteria and mould prone to causing stains, unpleasant odours and product deterioration.


(\*) **According to tests performed by the University of Perugia, Italy on:** *Staphylococcus aureus*, *Escherichia coli*, *Pseudomonas aeruginosa*, *Candida albicans*, *Aspergillus niger*, *Penicillium digitatum*.

In rare cases an allergic reaction may be caused by prolonged contact between seal and skin.

## Display

You can display all information and access all functions on the display.

There are three icons on the main menu, which you can select by rotating the SELECTOR to the right or to the left. A string is displayed with the name of the icon selected.



The icon  relates to SERVICES and if you select it by pressing the SELECTOR, a sub-menu is displayed with the following icons:


**kW** POWER CONSUMPTION: to display the instantaneous power absorbed by the washing machine.

 STATISTICS: to display the main statistics on use and energy and water consumption of the washing machine. You can also access this using the STATISTICS button on the control panel.

 DRIVE ME: to start the cycle guided selection process (see paragraph "Running a wash cycle").

 AUTO-CLEAN: to start the drum auto-clean cycle (see chapter on "Care and maintenance").

Consult the chapter SERVICES for more information.




The icon  relates to the SETTINGS and if you select it by pressing the SELECTOR, a sub-menu is displayed with the following icons:

 BRIGHTNESS: to set the display brightness.

 AUTOMATED KEY LOCK: There are four options to exclude or set the waiting time of the control panel automatic lock: 30" - 1' - 2' - 5'.

 LANGUAGE: to set the language in which all the display strings are displayed. The first time the machine is switched on, you will be asked to select the language and the display will automatically show the language selection menu. To select the language desired, turn the SELECTOR until it is highlighted, then press the SELECTOR.

 PRODUCT INFO: to display the washing machine serial number and code.



The icon  relates to the CYCLE SELECTION option.

If you select it by pressing the SELECTOR, a sub-menu is displayed with the available wash cycles icons:



Identify the cycle desired and confirm using the SELECTOR. Another sub-menu is displayed which you can use to customise the program by changing the Temperature and Spin Cycle values and selecting one or more wash options. You can also delay the program start time by up to 24h.



You can start the desired wash programme only from this sub-menu

Click on the first icon  to access the list of the last wash cycles performed, for which the type and adjustments/options selected have been stored (excluding any delayed start set).

If you select one of these last cycles, it is possible to start a wash cycle directly with the adjustments/options normally used and already set, without any further adjustments.

The following icons appear on the lower section of the display:


-  Door lock: displayed when the door is locked.
-  Button lock: displayed when the button lock is enabled.
-  DRIVE ME cycle: displayed on the recommended cycle screens and selected from DRIVE ME.

# Running a wash cycle

GB

## Traditional programming.

1. **SWITCH THE MACHINE ON.** Press the ON/OFF button. The word "HOTPOINT" appears on the display.
2. **LOAD THE LAUNDRY.** Open the washing machine door. Load the laundry while making sure not to exceed the maximum load quantity indicated in the programme table.
3. **MEASURE OUT THE DETERGENT.** Pull out the detergent dispenser drawer and pour the detergent into the relevant compartments as described in "Detergents and laundry".
4. **CLOSE THE DOOR.**
5. **SELECT THE WASH CYCLE.** Use the SELECTOR to select the icon  and press to access the sub-menu of the available wash cycles. After selecting and confirming the desired cycle with the SELECTOR, a sub-menu is displayed which you can use to customise the cycle by changing the Temperature and Spin Cycle values and/or selecting one or more options. The START/PAUSE light flashes slowly.
6. **START THE WASH CYCLE.** The wash cycle cannot start if you are in the options setting screen.



If necessary, press the "BACK" button to return to the cycle setting screen, from which it is possible to start the cycle by pressing the START/PAUSE button. The relevant indicator light will turn on and the door will lock (the DOOR LOCKED symbol  is lit). During the wash cycle, the name of the phase in progress will appear on the display. To change a wash cycle while it is in progress, pause the washing machine using the START/PAUSE button (the START/PAUSE indicator light will flash slowly in an orange colour); then select the desired cycle and press the START/PAUSE button again. To open the door while a cycle is in progress, press the START/PAUSE button; if the DOOR LOCKED  symbol is switched off the door may be opened. Press the START/PAUSE button again to restart the wash cycle from the point at which it was stopped.


7. **END OF THE PROGRAMME** This will be indicated by the text "CYCLE END" on the display; when the DOOR LOCKED symbol  switches off the door may be opened. Open the door, unload the laundry and switch off the machine.

! If you wish to cancel a cycle which has already begun, press and hold the ON/OFF button. The cycle will be stopped and the machine will switch off.

## DRIVE ME assisted programme

1. **SWITCH THE MACHINE ON.** Press the ON/OFF button. The word "HOTPOINT" appears on the display.
2. **LOAD THE LAUNDRY.** Open the washing machine door. Load the laundry while making sure not to exceed the maximum load quantity indicated in the programme table.
3. **MEASURE OUT THE DETERGENT.** Pull out the detergent dispenser drawer and pour the detergent into the relevant compartments as described in "Detergents and laundry".
4. **CLOSE THE DOOR.**

5. Access the DRIVE ME programme using the specific button on the control panel or using the SERVICES menu. The sub-menu will be displayed, in which you must choose the following:  
*Colour, Item/Fabric, Type of dirt, Type of detergent.* Once the machine has identified the optimum cycle for the choices made, you can only change the rinse type and set the delayed start if desired. The START/PAUSE light flashes slowly.
6. **START THE WASH CYCLE.** The wash cycle cannot start if you are in the options setting screen.



If necessary, press the "BACK" button to return to the cycle setting screen, from which it is possible to start the cycle by pressing the START/PAUSE button. The relevant indicator light will turn on and the door will lock (the DOOR LOCKED symbol  is lit). During the wash cycle, the name of the phase in progress will appear on the display. To change a wash cycle while it is in progress, pause the washing machine using the START/PAUSE button (the START/PAUSE indicator light will flash slowly in an orange colour); then select the desired cycle and press the START/PAUSE button again. To open the door while a cycle is in progress, press the START/PAUSE button; if the DOOR LOCKED  symbol is switched off the door may be opened. Press the START/PAUSE button again to restart the wash cycle from the point at which it was stopped.

7. **END OF THE PROGRAMME** This will be indicated by the text "CYCLE END" on the display; when the DOOR LOCKED symbol  switches off the door may be opened. Open the door, unload the laundry and switch off the machine.

! If you wish to cancel a cycle which has already begun, press and hold the ON/OFF button. The cycle will be stopped and the machine will switch off.

## Possibility of Adding Garments

An icon on the display will signal when additional garments can be introduced into the washing machine, without decreasing the washing performance.

To add garments, first stop the washing machine by pressing the START/PAUSE button then open the door and insert them. Press the START/PAUSE button again to restart the wash cycle from the point at which it was interrupted.

## Delayed start

In the options window the delayed start option is available, which allows for setting the delay time (with 1-hour intervals) before the cycle starts.



# Wash cycles and functions Hotpoint

GB

**Table of wash cycles**

Wash cycles	Max. temp. (°C)	Max. speed (rpm)	Detergents			Max. load (kg)	Residual damage%	Energy consumption kWh	Total water l	Cycle duration
			Pre-wash	Wash	Fabric softener					
<b>Anti-Stain Power 20°C</b>	20°	1600	-	●	●	10	-	-	-	*
<b>Anti-Stain Turbo 45'</b>	20° (Max. 40°C)	1200	-	●	●	5,5	-	-	-	*
<b>Cotton 20°C:</b> lightly soiled resistant and delicate colours.	20°	1600	-	●	●	10	-	-	-	*
<b>Cotton:</b> lightly soiled resistant and delicate colours.	90°	1600	●	●	●	10	-	-	-	*
<b>Synthetics:</b> heavily soiled resistant colours.	60°	1000	●	●	●	5,5	48	1,16	80	130'
<b>Synthetics (4):</b> lightly soiled resistant colours.	40°	1000	●	●	●	5,5	-	-	-	*
<b>Wool:</b> for wool, cashmere, etc.	40°	800	-	●	●	2,5	-	-	-	*
<b>Eco Cotton (1):</b> heavily soiled whites and resistant colours.	60°	1600	-	●	●	10	44	0,80	57,5	340'
<b>Eco Cotton (2):</b> lightly soiled resistant and delicate colours.	40°	1600	-	●	●	10	44	0,80	96	340'
<b>Eco Cotton (3):</b> lightly soiled resistant and delicate colours.	40°	1600	-	●	●	10	44	0,94	96	190'
<b>Shirts</b>	40°	600	-	●	●	2,5	-	-	-	*
<b>Jeans</b>	40°	800	●	●	●	5	-	-	-	*
<b>Duvets:</b> for down-stuffed garments.	30°	1000	-	●	●	3,5	-	-	-	*
<b>Lingerie</b>	40°	600	-	●	●	1	-	-	-	*
<b>Ultra Delicates</b>	30°	0	-	●	●	1	-	-	-	*
<b>Bed &amp; Bath 7 Days</b>	60°	1600	●	●	●	10	-	-	-	*
<b>Rinse</b>	-	1600	-	-	●	10	-	-	-	*
<b>Spin</b>	-	1600	-	-	-	10	-	-	-	*
<b>Pump out</b>	-	0	-	-	-	10	-	-	-	*

\* The duration of the wash cycle can be checked on the display.

The length of cycle shown on the display or in this booklet is an estimation only and is calculated assuming standard working conditions. The actual duration can vary according to factors such as water temperature and pressure, the amount of detergent used, the amount and type of load inserted, load balancing and any wash options selected.

- 1) Test wash cycle in compliance with regulations 1061/2010: set wash cycle ECO COTTON with a temperature of 60°C. This cycle is designed for cotton loads with a normal soil level and is the most efficient in terms of both electricity and water consumption; it should be used for garments which can be washed at 60°C. The actual washing temperature may differ from the indicated value.
- 2) Test wash cycle in compliance with regulations 1061/2010: set wash cycle ECO COTTON with a temperature of 40°C. This cycle is designed for cotton loads with a normal soil level and is the most efficient in terms of both electricity and water consumption; it should be used for garments which can be washed at 40°C. The actual washing temperature may differ from the indicated value.

For all Test Institutes:

- 3) Long wash cycle for cottons: set the ECO COTTON programme at temperature 40°C and select the DIRECT INJECTION option using "Power" mode.
- 4) Long wash cycle for synthetics: set wash cycle SYNTHETICS with a temperature of 40°C.

## Available options

! Only the options enabled for the programme chosen can be selected.

### Direct Injection

The washing machine is equipped with the innovative technology «Direct Injection» which pre-mixes water and detergent, thus immediately activating the detergent's cleaning principles. This active emulsion is directly introduced into the drum of the washing machine and penetrates the fibres with more efficacy in cleaning even heavily soiled garments at low temperatures, fully preserving colours and fabrics. The mode «Power» ensures the best cleaning performance and the mode «Eco Energy» allows more energy saving.

### Rinse

This option makes it possible to select the desired rinse type to protect sensitive skin. The first level relates to the "Normal Rinse". The second level is used to set the "Extra Rinse" level, which makes it possible to select an additional rinse to the standard cycle rinses, to eliminate all traces of detergent. The third level relates to the "Sensitive Skin" level, which makes it possible to select two additional rinses to the standard cycle rinses; it is recommended for very sensitive skin. The last level is the

"Anti Allergy" level, which makes it possible to select three additional rinses to the standard cycle rinses. The option - started with cycles at a temperature of 40°C - makes it possible to remove major allergens such as pollen, cat and dog hair. With cycles at a temperature higher than 40° a very good level of anti-allergic protection is achieved.

### Pre-wash

If this option is selected, the pre-wash cycle will run; this is useful for removing stubborn stains.

**N.B.:** Put the detergent in the relevant compartment.

### Soak

This option allows you to soak extremely dirty laundry.

### Easy Iron

By selecting this option, the wash and spin cycles will be modified in order to reduce the formation of creases. At the end of the cycle the washing machine will perform slow rotations of the drum. To end the cycle, press the START/PAUSE button.


### Post Care

At the end of the cycle the washing machine will perform slow rotations of the drum. To end the cycle, press the START/PAUSE button.


# Services

GB

You can access the SERVICES section from all product statuses except OFF, STANDBY and END. Access by turning the SELECTOR until the SERVICES icon is highlighted, then select the area by pressing it.




The SERVICES section contains the following items:




1. POWER CONSUMPTION: the instantaneous power absorbed by the washing machine is displayed (kW).
2. STATISTICS: the main statistics of the washing machine are displayed. You can also access this directly using the  button on the control panel.
3. DRIVE ME is a kind of Tutor which guides you in washing laundry. You select the parameters and the washing machine automatically identifies the most suitable cycle. You can also access this directly using the  button on the control panel (see chapter "Running a wash cycle").
4. AUTO-CLEAN to start the drum auto-clean cycle (see chapter on "Care and maintenance").

## 2. STATISTICS

You can access the STATISTICS section either by choosing the item on the SERVICES menu or by pressing the button  on the control panel, for direct access to the section.



2.1 SERVICES menu screen with the average consumption item highlighted.



2.2 SERVICES menu screen with the counters item highlighted.

There are two types of statistics: average consumption and counters. Both consider completed cycles only.

### AVERAGE CONSUMPTION

Select AVERAGE CONSUMPTION to display the average consumption of electricity (kWh) and water (litres) for the last 20 cycles run. The trend of the average compared with the previously reported averages is displayed alongside the average value, to indicate whether consumption is increasing or decreasing: an upwards red arrow indicates that average consumption is increasing and a downwards green arrow indicates that average consumption is decreasing (this indication will start after the 20th cycle).

TREND OF AVERAGE CONS.	
kWh	1,25 
Litres	15 

2.3 Average consumption screen.

### COUNTERS

Select the COUNTERS item to display:

- kWh: total kWh consumed (up to the last cycle).
- Litres: total litres of water consumed (up to the last cycle).
- N° cycles run (up to the last cycle).

	TOTAL	PARTIAL
kWh	25,14	10,24
Litres	80	11
No. of cycles	250	3
		

2.4 Counters screen

There are two types of the above 3 counters:

- TOTAL: these are calculated from when the product is installed.
- PARTIAL: these are calculated when the counters have been zeroed using the “RESET” button.

# Detergents and laundry

GB


## Detergent dispenser drawer

Good washing results also depend on the correct dose of detergent: adding too much detergent will not necessarily result in a more efficient wash, and may in fact cause a build up on the inside of your appliance and contribute to environmental pollution.

! Use powder detergent for white cotton garments, for pre-washing, and for washing at temperatures over 60°C.

! Follow the instructions given on the detergent packaging.

! Do not use hand washing detergents because these create too much foam.



Open the detergent dispenser drawer and pour in the detergent or washing additive, as follows.

**Compartment 1: Detergent for the prewash cycle (powder)**

**Compartment 2: Detergent for the wash cycle (powder or liquid)**

If liquid detergent is used, it is recommended that the removable plastic partition **A** (supplied) be used for proper dosage. If powder detergent is used, place the partition into slot **B**.

**Compartment 3: Additives (fabric softeners, etc.)**

The fabric softener should not overflow the grid.

## Preparing the laundry

- Divide the laundry according to:
  - the type of fabric/the symbol on the label
  - the colours: separate coloured garments from whites.
- Empty all garment pockets and check the buttons.
- Do not exceed the listed values, which refer to the weight of the laundry when dry: see "Table of wash cycles".

### How much does your laundry weigh?

- 1 sheet 400-500 g
- 1 pillow case 150-200 g
- 1 tablecloth 400-500 g
- 1 bathrobe 900-1200 g
- 1 towel 150-250 g

## Special wash cycles

**Anti-Stain Power 20°C:** this programme ensures maximum stain removal capacity with no need for pre-treatment at low temperatures, preserving fabrics and colours.

**Anti-Stain Turbo 45':** this cycle ensures excellent stain removal capacity even at 20°C in just 45 minutes. The temperature of this cycle can be increased up to 40°C.

**Cotton 20°C:** this programme is ideal for lightly soiled cotton loads. The effective performance levels achieved at cold temperatures, which are comparable to washing at 40°, are guaranteed by a mechanical action which operates at varying speed, with repeated and frequent peaks.

**Wool - Woolmark Apparel Care - Green:** the wool wash cycle of this machine has been approved

by The Woolmark Company for the washing of wool garments labelled as "hand wash" provided that the products are washed according to the instructions on the garment label and those issued by the manufacturer of this washing machine. (M1135)



**Shirts:** use the special wash cycle to wash shirts in different fabrics and colours to guarantee they receive the best possible care.

**Jeans:** turn garments inside-out before washing and use a liquid detergent. Use programme "Jeans".

**Duvets:** to wash double or single duvets (the weight of which should not exceed 3,5 kg), cushions or clothes padded with goose down such as puffer jackets, use the special "Duvets" wash cycle. We recommend that duvets are placed in the drum with their edges folded inwards (see figure) and that no more than ¾ of the total volume of the drum is used. To achieve the best results, we recommend that a liquid detergent is used and placed inside the detergent dispenser drawer.



**Lingerie:** for undergarments in any fabric and of any colour.

**Ultra Delicates:** use programme "Ultra Delicates" to wash very delicate garments having strasses or sequins. We recommend turning the garments inside out before washing and placing small items into the special bag for washing delicates. Use liquid detergent on delicate garments for best results.

**Bed & Bath 7 days:** use programme "Bed & Bath 7 days" to wash bed linen and towels in one single cycle: it optimises softener performance and helps you save time and energy. We recommend the use of powder detergent

## Load balancing system

Before every spin cycle, to avoid excessive vibrations and to distribute the load in a uniform manner, the drum rotates continuously at a speed which is slightly greater than the washing rotation speed. If, after several attempts, the load is not balanced correctly, the machine spins at a reduced spin speed. If the load is excessively unbalanced, the washing machine performs the distribution process instead of spinning. To encourage improved load distribution and balance, we recommend small and large garments are mixed in the load.

Your washing machine could occasionally fail to work. Before contacting the Technical Assistance Service (see “Service”), make sure that the problem cannot be solved easily using the following list.

## Problem:

**The machine does not switch on.**

**The wash cycle does not start.**

**The washing machine does not take in water (the text “No Water, turn on the tap” appears on the display).**

**The machine continuously fills with water and continually drains away or Water left in the drum or Stuck on wash.**

**The machine does not drain or spin - (error lights flashing).**

**The machine does spin.**

**The machine does not heat or poor wash results.**

**The programme takes too long.**

**The Display sticks at one ‘time to end’ for more than 1 Minute or the Display changes the estimated ‘Time to End’ during the programme.**

**The machine vibrates a lot during the spin cycle.**

## Possible causes / Solutions:

- The appliance is not plugged into the socket fully, or not enough to make contact.
- There is no power to the socket, or the fuse has blown in the mains plug.

- The door is not closed properly.
- The ON/OFF button has not been pressed.
- The START/PAUSE button has not been pressed.
- The water tap has not been turned on to allow water to flow into the machine.
- A delayed start has been set.

- The water inlet hose is kinked.
- The water inlet hose is not connected to the water supply.
- The water pressure is too low.
- The water tap has not been turned on to allow water to flow into the machine.
- There is no water supply to the house.
- The inlet valve filter is blocked.
- The START/PAUSE button has not been pressed.

- The top of the drain hose is too low - It must be fitted at a height between 65 and 100 cm from the floor (see “Installation”).
- The drain hose is connected incorrectly to the sink trap allowing water to run into the machine, the drain hose must be positioned higher than the bottom of the sink to prevent water flowing down the drain hose.
- The end of the drain hose has been pushed too far down the standpipe, the ‘U’ bracket should be fitted 100 mm from the end of the drain hose.

- The Pump filter is blocked.
- The EASY IRON option has been activated: To complete the wash cycle, press the START/PAUSE button (see “Available options”).
- The drain hose is kinked (see “Installation”).
- New Installation - The blanking cap or spigot has not been removed if connected under a sink.
- The drain hose or sink trap is blocked.

- The Spin Speed is set to “OFF”.

- The ‘Temperature’ is set to “OFF”.

- Programme times will vary due to water pressure, the incoming water temperature and if the wash load goes out of balance. This will increase the programme times accordingly (see ‘The machine wont spin properly’ next page).

- The display time is for guidance only - **it is not a precise time to finish and may vary.**

- The feet have not been adjusted, enabling the machine to rock.
- New Installation - Either the Transit Bolts including the plastic spacers, or the Polystyrene Packaging have not been removed when installing the machine.
- The machine is trapped between cabinets and/or walls.
- The load is in a slight out of balance condition and machine is spinning, but at a lower speed.

**The machine is noisy.**

- There will always be some motor, pump and drum noise during spin.

**The machine wont spin properly.**

- Out of Balance detected when attempting to go into a spin cycle - If this happens the machine will continue to try to repeat the distribution of the load required before the machine will go into higher spin speeds - This will increase the programme time accordingly. This is a safety feature to prevent damage. Out of Balance can be caused by washing a single heavy item (eg duvet, quilt, etc). - Try the programme again using a different load.

**The machine leaks from the dispenser.**

- The dispenser drawer is blocked with detergent and requires cleaning.
- The water pressure is too high and requires turning down - turn down the tap on the water supply pipe slightly and try again.
- The machine is tilting forwards - It must be level when in its final position.

**The machine leaks (other than dispenser).**

- The fill hose is loose, check both the cabinet and tap ends.
- The fill hose is tight but still leaks, if so replace the rubber washers, or the fill hose is missing the rubber washer.
- The drain hose is not fixed in properly.

**The machine is locked and the display indicating an error code (e.g. F-01, F-..).**

- Switch off the machine and unplug it, wait for approximately 1 minute and then switch back on again. If the problem persists contact Technical Assistance Centre.

**The machine smells.**

- The machine requires a service wash. Run a auto clean wash cycle with detergent and no laundry.

**The machine door cannot be opened.**

- The door will not open until the door lock indicator light goes out shortly after the program has finished.
- If there is no power to the machine you need to perform the manual unlocking procedure.

**Door Seal damaged at the bottom.**

- The door seal has drainage holes at the bottom - This is normal.

**The water level is too low when the machine is washing.**

- The water level is correct if it can be seen at the bottom of the door.

**There is too much foam.**

- The detergent is not suitable for machine washing (it should display the text 'for washing machines' or 'hand and machine wash' or the like).
- Too much detergent was used - less detergent is required in soft water.

**After completing the programme, or before starting a programme, the machine has turned itself off (no lights).**

- To comply with new energy saving regulations the machine is fitted with an automatic standby system. Press 'ON/OFF' button for 3 seconds to activate the machine, it can then either be switched off or a new programme selected.

**General.**

- Your washing machine contains sensors that monitor progress during the wash cycle (eg: Water Levels, Temperatures, Out of Balance loads, Wash time/progress). Normally, if your machine successfully completes the cycle, there is unlikely to be anything wrong!

**Remember, you will be charged for a service call for problems caused by incorrect installation, as indicated on pages 2 to 4.**

**Not emptying contents from pockets may cause pump or drain blockages, or may damage the machine. Do not wash items which do not have a wash label, or wash items that are not intended as machine washable.**

## Guarantee

### 12 Months Parts and Labour Guarantee

Your appliance has the benefit of our manufacturer's guarantee, which covers the cost of breakdown repairs for twelve months from the date of purchase. This gives you the reassurance that if, within that time, your appliance is proven to be defective because of either workmanship or materials, we will, at our discretion, either repair or replace the appliance at no cost to you:

This guarantee is subject to the following conditions:

- The appliance has been installed and operated correctly and in accordance with our operating and maintenance instructions.
- The appliance is used only on the electricity or gas supply printed on the rating plate.
- The appliance has been used for normal domestic purposes only.
- The appliance has not been altered, serviced, maintained, dismantled, or otherwise interfered with by any person not authorised by us.
- Any repair work must be undertaken by us or our appointed agent.
- Any parts removed during repair work or any appliance that is replaced become our property.
- The appliance is used in the United Kingdom or Republic of Ireland.

The guarantee does not cover:

- Damage resulting from transportation, improper use, neglect or interference or as a result of improper installation.
- Replacement of any consumable item or accessory. These include but are not limited to: plugs, cables, batteries, light bulbs, fluorescent tubes and starters, covers and filters.
- Replacement of any removable parts made of glass or plastic.

THIS GUARANTEE WILL NOT APPLY IF THE APPLIANCE HAS BEEN USED IN COMMERCIAL OR NON-DOMESTIC PREMISES.

## Recycling and Disposal Information

As part of Hotpoint's continued commitment to helping the environment, Hotpoint reserves the right to use quality, recycled components to keep down customer costs and minimise material wastage. Please dispose of packaging and old appliances carefully. To minimise the risk of injury to children, remove the door, plug, and cut the mains cable off flush with the appliance. Dispose of these parts separately to ensure that the appliance can no longer be plugged into mains socket, and the door cannot be locked shut.

## Repairs and After Sales

For product help and advice, repairs, spare parts or accessories, we're here to help.


For local repair engineers - **03448 111 606**  
ROI - **0818 313 413**

UK standard local rate applies  
ROI local Irish rate applies

For Parts and Accessories visit:  
**parts.hotpoint.co.uk/shop**

Please remember to register your appliance at **www.hotpointservice.co.uk** to activate your 10 year parts guarantee.

How to find your model and serial number:



**COMMISSION DELEGATED REGULATION (EU) No 1061/2010**

Brand	HOTPOINT
Model	RZ 1066 B UK
Rated capacity in kg of cotton	10
Energy efficiency class on a scale from A+++ (low consumption) to G (high consumption)	A+++
Energy consumption per year in kWh <sup>1)</sup>	166
Energy consumption of the standard 60 °C cotton programme at full load in kWh <sup>2)</sup>	0.805
Energy consumption of the standard 60 °C cotton programme at partial load in kWh <sup>2)</sup>	0.679
Energy consumption of the standard 40 °C cotton programme at partial load in kWh <sup>2)</sup>	0.626
Power consumption of the off-mode in W	0.5
Power consumption of the left-on mode in W	8
Water consumption per year in litres <sup>3)</sup>	12460
Spin-drying efficacy class on a scale from G (minimum efficacy) to A (maximum efficacy)	A
Maximum spin speed attained <sup>4)</sup>	1600
Remaining moisture content <sup>5)</sup>	44.0%
Programme time of the "standard 60 °C cotton" at full load in minutes	340
Programme time of the "standard 60 °C cotton" at partial load in minutes	240
Programme time of the "standard 40°C cotton" at partial load in minutes	215
Duration of the left-on mode in minutes	30
Noise in dB(A) re 1 pW washing <sup>6)</sup>	56
Noise in dB(A) re 1 pW spinning <sup>6)</sup>	78
Built-in model	

<sup>1)</sup> The "standard 60°C cotton" at full and partial load and the "standard 40°C cotton" at partial load are the standard washing programmes to which the information in the label and the fiche relates. Standard 60°C cotton and standard 40°C cotton are suitable to clean normally soiled cotton laundry and are the most efficient programmes in terms of combined energy and water consumption. Partial load is half the rated load.

<sup>2)</sup> Based on 220 standard washing cycles for cotton programmes at 60°C and 40°C at full and partial load, and the consumption of the low-power modes. Actual energy consumption will depend on how the appliance is used.

<sup>3)</sup> Based on 220 standard washing cycles for cotton programmes at 60°C and 40°C at full and partial load. Actual water consumption will depend on how the appliance is used.

<sup>4)</sup> For the standard 60 °C at full and partial load or the 40°C at partial whichever is lower.

<sup>5)</sup> Attained for 60 °C cotton at full and partial load or the 40°C at partial whichever is higher.

<sup>6)</sup> Based on washing and spinning phases for the standard 60°C cotton programme at full load.



GB

Indesit Company Spa  
Viale Aristide Merloni, 47  
60044 Fabriano (AN)  
Italy  
[www.hotpoint.co.uk](http://www.hotpoint.co.uk)

---