

Instructions for use

KitchenAid

Important safety instructions	4
Installation	8
Safeguarding the environment	9
Eco Design Declaration	9
Troubleshooting guide	9
After-Sales Service	10
Cleaning	10
Maintenance	11
Instructions for using the oven	12
Functions description table	20
Cooking table	22
Tested recipes	24
Recommended use and tips	25

Important safety instructions

SAFETY IS OUR PRIORITY

This manual and the appliance itself display important safety warnings, to be read and observed at all times.



This is the danger symbol relating to safety, which alerts users to potential risks to themselves and others. All safety warnings are preceded by the danger symbol and the text shown here:

DANGER

Indicates a hazardous situation which, if not avoided, will cause serious injury.

WARNING

Indicates a hazardous situation which, if not avoided, could cause serious injury.

All safety warnings give specific details of the potential risk present, and indicate how to reduce the risk of injury, damage and electric shock resulting from improper use of the appliance. Carefully observe the following instructions:

- Wear protective gloves when unpacking and installing the appliance.
- The appliance must be disconnected from the power supply before installation.
- Installation and maintenance must be carried out by a qualified technician, in compliance with the manufacturer's instructions and local safety regulations. Do not repair or replace any part of the appliance unless specifically stated in the user manual.
- Replacement of power cables must be carried out by a qualified electrician. Contact an authorised After-Sales Service.
- Regulations require that the appliance be earthed.
- Once the appliance is fitted in its housing, the power cable must be long enough to connect the appliance

to the mains power supply.

- For installation to comply with current safety regulations, an omnipolar disconnect switch with a minimum contact gap of 3 mm must be used.
- Do not use multiple plug adaptors if the oven is fitted with a plug.
- Do not use extension leads.
- Do not pull the power supply cable.
- The electrical components must not be accessible to the user after installation.
- Do not use the surface of the induction plate if it is cracked, and switch off the appliance to avoid the possibility of electric shock (only for models with induction function).
- Do not touch the appliance with any wet part of the body and do not operate it when barefoot.
- This appliance is designed solely for use as a domestic appliance, for cooking food. No other use is permitted (e.g. heating rooms). The manufacturer shall accept no responsibility for the controls being used inappropriately or set incorrectly.
- The appliance and its accessible parts become hot during use.
- Care should be taken to avoid touching heating elements.
- Very young (0-3 years) and young children (3-8 years) must be kept away unless continuously supervised.
- Children aged 8 years and above, and persons with reduced physical, sensory or mental capabilities or lack of experience and knowledge can only use this appliance if they are supervised or have been given instructions on safe appliance use, and if they understand the hazards involved. Children must not play with the appliance. Cleaning and user maintenance must not be carried out by children

without supervision.

During and after use, do not touch the heating elements or interior surfaces of the appliance – risk of burns. Do not allow the appliance to come into contact with cloths or other flammable materials until all the components have cooled down completely.

- At the end of cooking, exercise caution when opening the appliance door, letting the hot air or steam exit gradually before accessing the oven. When the appliance door is shut, hot air is vented from the aperture above the control panel. Do not obstruct the vent apertures.
- Use oven gloves to remove pans and accessories, taking care not to touch the heating elements.
- Do not place flammable materials in or near the appliance: a fire may break out if the appliance is inadvertently switched on.
- Do not heat or cook sealed jars or containers in the appliance.
- The pressure that builds up inside might cause the jar to explode, damaging the appliance.
- Do not use containers made of synthetic materials.
- Overheated oils and fats catch fire easily. Always remain vigilant when cooking foods rich in fat and oil.
- Never leave the appliance unattended during food drying.
- If alcoholic beverages are used when cooking foods (e.g. rum, cognac, wine), remember that alcohol evaporates at high temperatures. As a result, there is a risk that vapours released by the alcohol may catch fire upon coming into contact with the electrical heating element.

- Never use steam cleaning equipment.
- Do not touch the oven during the pyrolysis cycle. Keep children away from the oven during the pyrolysis cycle. Any excess spillage must be removed from the oven cavity before the cleaning cycle (only for ovens with pyrolysis function).
- During and after the pyrolysis cycle, animals must be kept away from the area where the appliance is located (only for ovens with the Pyrolysis function).
- Use only the temperature probe recommended for this oven.
- Do not use harsh abrasive cleaners or sharp metal scrapers to clean the oven door glass as they can scratch the surface, which may result in the glass shattering.
- Ensure that the appliance is switched off before replacing the lamp to avoid the possibility of electric shock.
- Do not use aluminium foil to cover food in the cooking vessel (only for ovens with a cooking vessel supplied).

SCRAPPING OF HOUSEHOLD APPLIANCES

- This appliance is manufactured with recyclable or reusable materials. Scrap the appliance in accordance with local regulations on waste disposal. Before scrapping, cut off the power cords so that the appliances cannot be connected to the mains.
- For further information on the treatment, recovery and recycling of household electrical appliances, contact your competent local authority, the collection service for household waste or the store where you purchased the appliance.

Installation

After unpacking the oven, ensure that it has not been damaged during transit and that the oven door closes properly.

In the event of problems, contact the dealer or your nearest After-Sales Service. To avoid any damage, only remove the oven from its polystyrene foam base at the time of installation.

PREPARING THE HOUSING UNIT

- Kitchen units in contact with the oven must be heat-resistant (min 90 °C).
- Carry out all cabinet cutting work before fitting the oven in the housing unit, and carefully remove all wood chips and sawdust.
- After installation, the bottom of the oven must no longer be accessible.
- For correct appliance operation, do not obstruct the minimum gap between the worktop and the upper edge of the oven.

Electrical connection

Ensure that the power voltage specified on the appliance rating plate is the same as the mains voltage. The rating plate is on the front edge of the oven (visible when the door is open).

- Replacement of power cables (type H05 RR-F 3 x 1.5 mm²) must be carried out by a qualified electrician. Contact an authorised After-Sales Service.

The oven is programmed to operate with power absorption above 2.5 kW (indicated by "HIGH" in the settings, as shown in the figure below) which is compatible with a domestic power supply above 3 kW. If the household has a lower power supply, the setting must be lowered ("LOW" in the settings). The table below details the recommended electrical power settings for the various countries.

COUNTRY	ELECTRICAL POWER SETTING
GERMANY	HIGH
SPAIN	LOW
FINLAND	HIGH
FRANCE	HIGH
ITALY	LOW
NETHERLANDS	HIGH
NORWAY	HIGH
SWEDEN	HIGH
U.K.	LOW
BELGIUM	HIGH

1. To change the power absorption setting, turn the "Functions" knob to "CLOCK" and then select "POWER" using the "Browse" knob.
2. Press  to access the setting.
3. Turn the "Browse" knob to select the setting you require and confirm by pressing the  button.

GENERAL RECOMMENDATIONS

Before use:

- Remove any protective pieces of cardboard, protective film and adhesive labels from the oven and the accessories.
- Remove the accessories from the oven and heat it at 200°C for about an hour to eliminate the smell and fumes from the protective grease and insulating materials.

During use:

- Do not place heavy objects on the door as they could damage it.
- Do not cling to the door or hang anything from the handle.
- Do not cover the inside of the oven with aluminium foil.
- Do not pour water into the inside of a hot oven; this could damage the enamel coating.
- Do not drag pots or pans across the bottom of the oven as this could damage the enamel coating.
- Make sure that the electrical cables of other appliances do not touch hot parts of the oven or become trapped in the door.
- Do not expose the oven to atmospheric agents.

Safeguarding the environment

Disposal of packing materials

- The packaging materials are 100% recyclable and are marked with the recycling symbol .
- The various parts of the packing must therefore be disposed of responsibly and in full compliance with local authority regulations governing waste disposal.



Appliance scrapping

- This appliance is marked in compliance with European Directive 2012/19/EU on Waste Electrical and Electronic Equipment (WEEE).
- By ensuring correct disposal of the product, the user can help prevent potential negative consequences for the environment and human health.
- The  symbol on the product or on the

accompanying documentation indicates that it should not be treated as domestic waste but must be taken to an appropriate collection centre for the recycling of electrical and electronic equipment.

Energy saving tips

- Only preheat the oven if specified in the cooking table or your recipe.
- Use dark lacquered or enamelled baking moulds as they absorb heat far better.

Eco Design Declaration

- This appliance meets the Ecodesign requirements of European Regulation No. 65/2014 and No. 66/2014 and complies with the European Standard EN 60350-1.

Troubleshooting guide

The oven does not work:

- Check the mains electrical power and ascertain whether the oven is connected to the electrical supply.
- Switch the oven off and then on again to see whether this eliminates the fault.

The electronic programmer does not work:

- If the display shows the letter "F" followed by a number, contact your nearest After-Sales Service. In this case, specify the number after the letter "F".

After-Sales Service

Before contacting the After-Sales Service:

- See if you can solve the problem yourself with the help of the suggestions given in the "Troubleshooting guide".
- Switch the appliance off and then on again it to see whether the problem has been eliminated.

If the fault persists after the above checks, contact the nearest After-Sales Service.

Always specify:

- a brief description of the fault;
- the type and exact model of the oven;
- the service number (number after the word "Service" on the rating plate), located on the right-hand edge of the cooking compartment

Cleaning

WARNING

- Do not use steam cleaners.
- Do not clean the oven until it is cool to the touch.
- Disconnect the appliance from the mains power supply.

Oven exterior

IMPORTANT: do not use corrosive or abrasive detergents. If any of these products comes into contact with the appliance, clean immediately with a damp microfibre cloth.

- Clean the surfaces with a damp microfibre cloth. If it is very dirty, add a few drops of washing up detergent to the water. Finish off with a dry cloth.

Oven interior

IMPORTANT: do not use abrasive sponges or metallic scrapers or scourers. Over time, these can ruin enamelled surfaces and the oven door glass.

- After each use, allow the oven to cool then clean it preferably while it is still warm, in order to remove built-up dirt and stains caused by food residues (e.g. food with a high sugar content).
- Do not use corrosive or abrasive detergents.
- Clean the door glass with a suitable liquid detergent. The oven door can be removed to facilitate cleaning (see MAINTENANCE).

(visible when the oven door is open). The service number is also indicated on the guarantee booklet;

- your full address;
- your telephone number.

SERVICE 0000 000 00000



If any repairs are required, contact an **authorised After-Sales Service** (to guarantee use of original spare parts and correct repair).

N.B: during prolonged cooking of foods with a high water content (e.g. pizza, vegetables, etc.) condensation may form on the inside of the door and around the seal. When the oven is cold, dry the inside of the door with a cloth or sponge.

Accessories:

- Soak the accessories in water with washing-up detergent immediately after use, handling them with oven gloves if still hot.
- Food residues can be easily removed using a washing-up brush or sponge.

Maintenance



WARNING

- Use safety gloves.
- Ensure that the oven is cold before carrying out the following operations.
- Disconnect the appliance from the mains power supply.

REMOVING THE DOOR

To remove the door:

1. Open the door fully.
2. Lift the catches and push them forwards as far as they will go (fig. 1).
3. Close the door as far as it will go (A), lift it up (B) and turn it (C) until it is released (D) (fig. 2).




Fig. 1

To refit the door:

1. Insert the hinges in their seats.
2. Open the door fully.
3. Lower the two catches.
4. Close the door.




Fig. 2

REMOVING THE SIDE GRILLES

The side accessory-holder grilles are equipped with two fixing screws (fig. 3) for optimum stability.

1. Remove the screws and corresponding plates on the right and left with the aid of a coin or tool (fig. 4).
2. To remove the grilles, lift them up (1) and turn them (2) as shown in fig. 5.




Fig. 3

REPLACING THE LAMP

To replace the rear lamp (if fitted)

1. Disconnect the oven from the mains power supply.
2. Unscrew the lamp cover, replace the lamp (see note for lamp type) and screw the lamp cover back on.
3. Reconnect the oven to the power supply.




Fig. 4

N.B:

- Only use 25-40 W/230 V type E-14, T300 °C incandescent lamps, or 20-40 W/230 V type G9, T300 °C halogen lamps.
- The lamp used in the appliance is specifically designed for electrical appliances, and is not suitable for household room illumination (Commission Regulation (EC) no. 244/2009).
- Lamps are available from our After-Sales Service.





Fig. 5

IMPORTANT:

- If using halogen lamps, do not handle with bare hands as fingerprints can damage them.
- Do not use the oven until the lamp cover has been put back in place.

Instructions for using the oven

FOR ELECTRICAL CONNECTION, SEE THE PARAGRAPH ON INSTALLATION



1. Control panel
2. Upper heating element/grill
3. Cooling fan (not visible)
4. Rating plate (not to be removed)
5. Lamps
6. Circular heating element (not visible)
7. Fan
8. Rotisserie (if supplied)
9. Bottom heating element (not visible)
10. Door
11. Position of shelves (the number of shelves is indicated on the front of the oven)
12. Rear wall


N.B:

- During cooking, the cooling fan may switch on at intervals in order to minimise energy consumption.
- At the end of cooking, after the oven has been switched off, the cooling fan may continue to run for a while.
- When the oven door is opened during cooking, the heating elements switch off.

Instructions for using the oven

ACCESSORIES SUPPLIED

A. WIRE SHELF: the wire shelf can be used to grill food or as a support for pans, cake tins and other oven-proof cookware.



(Fig. A)

B. BAKING TRAY: for making bread and pastry products, but also roasts, fish en papillote, etc.




(Fig. C)

C. DRIP TRAY: the drip tray is designed to be positioned under the wire shelf in order to collect fat or as an oven tray for cooking meat, fish, vegetables, focaccia, etc.



(Fig. C)

D. SLIDING SHELVES (if fitted): for easier handling of shelves and trays.



(Fig. D)

The number of accessories may vary according to which model is purchased.



ACCESSORIES NOT SUPPLIED

Other accessories can be purchased separately from the After-Sales Service.


Instructions for using the oven

INSERTING WIRE SHELVES AND OTHER ACCESSORIES IN THE OVEN

1. Insert the wire shelf horizontally, with the raised part "A" facing upwards (fig. 1).
2. Other accessories, such as the drip tray and baking tray, are inserted in the same way as the wire shelf (fig. 2).




CONTROL PANEL DESCRIPTION



1. **FUNCTIONS KNOB:** On/off and function selector knob
2. **BROWSE KNOB:** for browsing the menu and adjusting pre-set values
3. **BUTTON** ⏪: to return to the previous screen
4. **BUTTON** ✓: to select and confirm settings

Instructions for using the oven

DESCRIPTION OF DISPLAY




- A.** Display of heating elements activated during the various cooking functions
- B.** Time management symbols: timer, cooking time, end of cooking time, time
- C.** Information regarding selected functions
- D.** Automatic BREAD/PIZZA function selected
- E.** Indication of door locked during automatic cleaning cycle (pyro-cleaning)
- F.** Internal oven temperature
- G.** Pyro-cleaning function (not available on this model)
- H.** Browning
- I.** Special functions: defrosting, warm keeping, yogurt, rising, meat slow cooking, fish slow cooking, Eco Forced air.

STARTING THE OVEN – SETTING LANGUAGE

When the oven is first switched on, the display will show ENGLISH.

Turn the “Browse” knob until the language you require is displayed, then press the  button to confirm.

SETTING THE TIME



After setting the language, the time must be set on the clock. The two hour digits flash on the display.

1. Turn the “Browse” knob to display the correct hour.
2. Press the button  to confirm; the two minute digits flash on the display.
3. Turn the “Browse” knob to display the correct minutes.
4. Press button .

To change the time, e.g. following a power cut, see the next section (SETTINGS).

SELECTING COOKING FUNCTIONS



1. Turn the “Functions” knob to the function you require: The cooking settings are shown on the display.
2. If the values shown are those desired, press . To change them, proceed as indicated below.

Instructions for using the oven

SETTING THE TEMPERATURE/OUTPUT OF THE GRILL

To change the temperature or output of the grill, proceed as follows:



1. Turn the "Browse" knob to display the value you require.
2. Press button  to confirm.

FAST PREHEATING



1. Turn the "Functions" knob to select the fast preheating function.
2. Confirm by pressing : the settings are shown on the display.
3. If the proposed temperature is that desired, press button . To change the temperature, proceed as described in previous paragraphs. The message PRE appears on the display. When the set temperature is reached, the corresponding value (e.g. 200 °C) appears on the display and the acoustic signal sounds.


At the end of preheating, the oven automatically selects the conventional function.

At this point food can be placed in the oven for cooking.

4. If you want to set a different cooking function, turn the "Functions" knob and select the function you require.

SETTING COOKING TIME

This function can be used to cook food for a set length of time, from a minimum of 1 minute to the maximum time allowed by the selected function, after which the oven switches off automatically.



1. Once the temperature is confirmed, the symbol  flashes.
2. Turn the "Browse" knob to display the cooking time you require.
3. To confirm the cooking time, press button .

SETTING END OF COOKING TIME / DELAYED START


IMPORTANT: The delayed start setting is not available for the following functions: FAST PREHEATING, BREAD/PIZZA.

N.B. with this setting, the selected temperature is reached in a more gradual way, so cooking times will be slightly longer than those stated in the cooking table.

The end of cooking time can be set, delaying the start of cooking by up to a maximum of 23 hours and 59 minutes. This can only be done once the cooking time has been set.

After setting the cooking time, the display shows the end cooking time (e.g. 15:45) and the  symbol flashes.

Instructions for using the oven



To delay the end cooking time (and therefore the time at which cooking starts as well), proceed as follows:

1. Turn the "Browse" knob to display the time at which you want cooking to end (e.g. 16:00)
2. Confirm the selected value by pressing button : the two dots in the end cooking time will flash, indicating that the setting has been applied correctly.
3. The oven will automatically delay the start of cooking so as to finish cooking at the set time.

The various settings (temperature, grill setting, cooking time) can be changed at any time by pressing the button to go back, turning the "Browse" knob to change the settings and then pressing the button to confirm.

Delay to start functionality is not available for Grill and Turbo Grill functions.

TIMER



This function can only be used with the oven switched off and can be used, for example, to monitor the cooking time of pasta.

The maximum time which can be set is 23 hours and 59 minutes.

1. With the "Functions" knob at zero, turn the "Browse" knob to display the time you require.
2. Press button to start the countdown. When the set time has elapsed, the display will show "END" and an acoustic signal will sound. To mute the acoustic signal, press button (the time of day appears on the display).

SELECTING SPECIAL FUNCTIONS

Turn the "Functions" knob to "DEFROST" to access a submenu containing seven special functions.

To browse, select and start one of these functions, proceed as follows:



1. Turn the "Functions" knob to "DEFROST" along with this function's corresponding symbol.
2. Turn the "Browse" knob to scroll through the list of functions: DEFROST, WARM KEEPING, YOGURT, RISING, MEAT SLOW COOKING, FISH SLOW COOKING, ECO FORCED AIR.
3. Press button to confirm.

Instructions for using the oven

BROWNING

At the end of cooking, with certain functions, the display indicates the possibility of browning. This function can only be used when cooking time has been set.



Once the cooking time has ended, the display shows: "PRESS  TO BROWN". Press button , and the oven starts a 5-minute browning cycle. This function can be selected consecutively a maximum of twice.

BREAD/PIZZA FUNCTION SELECTION

Turn the "Functions" knob to "BREAD" to access a submenu containing two automatic cooking functions for baking bread and cooking pizza.

Bread



1. Turn the "Functions" knob to "BREAD" and AUTO at the side.
2. Press  to select the function.
3. Turn the "Browse" knob to set the required temperature (between 180 °C and 220 °C) and confirm by pressing the  button.
4. Turn the "Browse" knob to set the required cooking time and press  to start cooking.

Pizza



1. Turn the "Functions" knob to "BREAD". To select the "PIZZA" function, proceed as follows:
2. Turn the "Browse" knob: "PIZZA" appears on the display.
3. Press  to select the function.
4. Turn the "Browse" knob to set the required temperature (between 220 °C and 250 °C) and confirm by pressing the  button.
5. Turn the "Browse" knob to set the required cooking time and press  to start cooking.

Instructions for using the oven

SETTINGS

Turn the "Functions" knob to "CLOCK" to access a submenu containing five display settings which can be changed.

Clock

Turn the "Browse" knob until "CLOCK" is displayed. To change the time of day, see the previous paragraph (SETTING THE TIME).

Brightness

To change the display brightness, proceed as follows:

1. Turn the "Browse" knob until "BRIGHTNESS" is displayed.
2. Press button : number 1 appears on the display.
3. Turn the "Browse" knob to increase or decrease the brightness and confirm by pressing .

Sound

To activate or deactivate the acoustic signal, proceed as follows:

4. Turn the "Browse" knob until "SOUND" is displayed.
5. Press  to access the setting (ON/OFF).
6. Turn the "Browse" knob to select the setting you require and confirm by pressing the  button.

Eco

With the ECO mode selected (ON), the display reduces the brightness, showing the clock when the oven is in stand-by position for 3 minutes. To view information on the display, simply press a button or turn a knob.

1. Turn the "Browse" knob until "ECO" is displayed.
2. Press  to access the setting (ON/OFF).
3. Turn the "Browse" knob to select the setting you require and confirm by pressing the  button.
4. If Eco mode is activated during a cooking function, the light inside the oven will be switched off after one minute of cooking. It will switch on again if the user presses any buttons or turns any knobs on the appliance.

Power

1. To change the power absorption setting, turn the "Functions" knob to "CLOCK" and then select "POWER" using the "Browse" knob.
 2. Press  to access the setting
 3. Turn the "Browse" knob to select the setting you require and confirm by pressing the  button.
- See the relevant part of the INSTALLATION section (page 8) for more information.

Language

1. Turn the "Browse" knob until "LANGUAGE" is displayed.
2. Press  to access the setting.
3. Turn the "Browse" knob until the language you require is displayed, then press the  button to confirm.

KEY-LOCK

This function can be used to lock the buttons and knobs on the control panel.



To activate it, press  and  at the same time for at least 3 seconds. When activated, the functions associated with the buttons are locked and the display shows a key symbol. This function can also be activated during cooking. To deactivate it, repeat the above procedure. When the key-lock function is activated, the oven can be switched off by turning the knob to 0 (zero). In this case, however, the previously selected function will have to be set again.

Functions description table

FUNCTION SELECTOR KNOB			
	OFF	To stop cooking and switch off the oven.	
	LAMP	To switch the oven interior light on/off.	
SPECIAL FUNCTIONS	BROWSE KNOB	 DEFROST	To speed up defrosting of food. Place food on the middle shelf. Leave food in its packaging in order to prevent it from drying out on the outside.
		 WARM KEEPING	For keeping just-cooked food hot and crisp (e.g: meat, fried food or flans). Place food on the middle shelf. The function will not activate if the temperature in the oven is above 65°.
		 YOGURT	For preparing homemade yogurt. Use small china jars or aluminium foil baking cups. Cover with aluminium foil before placing in the appliance. Position the drip tray with the containers on the 1st shelf. The oven does not have to be preheated.
		 RISING	For optimal rising of sweet or savoury dough. Place the dough on the 2nd shelf. The oven does not have to be preheated. To safeguard the quality of proving, do not activate the function if the oven is still hot after a cooking cycle.
		 MEAT SLOW COOKING	For slowly cooking meat at 90 °C. This function offers slow cooking which ensures the food remains tender and succulent. Sear roasting joints in a pan first to brown the meat and help seal in its natural juices. Cooking times range from 4 hours for 1 kg joints to 6-7 hours for 3 kg joints. For optimum results, avoid opening the oven door during cooking and use a cooking thermometer to check the core temperature of the meat.
		 FISH SLOW COOKING	For gently cooking fish at 85 °C. This function offers slow cooking which ensures the food remains tender and succulent. Thanks to the low temperature, the food does not brown on the outside and the end result is similar to steam cooking. Cooking times range from 2 hours for 300 g of fish to 4-5 hours for 3 kg of fish. For optimum results, keep the oven door openings to a minimum during cooking in order to avoid heat dispersion.
		 ECO FORCED AIR	To cook stuffed roasts and pieces of meat on one shelf. This function uses discontinuous, delicate fan assistance, which prevents excessive drying of foods. In this ECO function, the light remains off during cooking and can be temporarily switched on by pressing the confirm button. To use the ECO cycle and therefore optimise power consumption, the oven door should not be opened until the food is completely cooked. It is advisable to use the 3rd level. The oven does not have to be preheated.
	CONVENTIONAL	For cooking any kind of dish on one shelf only. Use the 3rd shelf. To make pizza, savoury pies and sweets with liquid fillings, use the 1st or 2nd shelf. Preheat the oven before placing food inside.	
	CONVECTION BAKE	For cooking meat and pies with a liquid filling (savoury or sweet) on a single shelf. Use the 3rd shelf. Preheat the oven before cooking.	
	FORCED AIR	For cooking a variety of food requiring the same cooking temperature on two shelves at the same time (e.g: fish, vegetables, cakes). This function can be used to cook different foods without odours being transferred from one food to another. Use the 2nd shelf to cook on one shelf only. To cook on two shelves, use the 1st and 4th shelves after preheating the oven.	

Functions description table

FUNCTION SELECTOR KNOB			
	MAXI COOKING		To cook large joints of meat (over 2.5 kg). Use the 1st or 2nd shelves, depending on the size of the joint. The oven does not have to be preheated. It is advisable to turn the meat over during cooking for more even browning. It is best to baste the meat every now and again to prevent it from drying out.
GRILL FUNCTIONS	BROWSE KNOB	 GRILL	For grilling steak, kebabs and sausages; for cooking vegetables au gratin and toasting bread. Place food on the 4th or 5th shelf. When grilling meat, use the drip tray to collect the cooking juices. Position it on the 3rd/4th shelf, adding approx. half a litre of water. The oven does not have to be preheated. During cooking, the oven door must remain closed.
		 TURBO GRILL	For roasting large joints of meat (legs, roast beef, chicken). Position the food on the middle shelves. Use the drip tray to collect the cooking juices. Position it on the 1st/2nd shelf, adding approx. half a litre of water. The oven does not have to be preheated. During cooking, the oven door must remain closed. With this function, you can also use the turnspit, if provided.
SETTINGS	BROWSE KNOB	CLOCK BRIGHTNESS SOUND ECO POWER LANGUAGE	For setting the display (language, time, brightness, volume, energy saving).
BREAD / PIZZA	BROWSE KNOB	 BREAD	For baking different types and sizes of pizza and bread. This function contains two programmes with predefined settings. Simply indicate the values required (temperature and time), and the oven will manage the cooking cycle automatically. Place the dough on the 2nd shelf after preheating the oven.
		 PIZZA	
	FAST PREHEATING		To preheat the oven rapidly.

Cooking table

Recipe	Function	Pre-heating	Shelf (from bottom)	Temperature (°C)	Time (mins)	Accessories
Leavened cakes		YES	2 / 3	160 – 180	30 – 90	Cake tin on wire shelf
		YES	1 – 4	160 – 180	30 – 90	Shelf 4: cake tin on wire shelf Shelf 1: cake tin on wire shelf
Filled pies (cheesecake, strudel, apple pie)		YES	3	160 – 200	30 – 85	Drip tray/ baking tray or cake tin on wire shelf
		YES	1 – 4	160 – 200	35 – 90	Shelf 4: cake tin on wire shelf Shelf 1: cake tin on wire shelf
Biscuits/tartlets		YES	3	170 – 180	15 – 45	Drip tray / baking tray
		YES	1 – 4	160 – 170	20 – 45	Shelf 4: wire shelf Shelf 1: drip tray / baking tray
Choux pastry		YES	3	180 – 200	30 – 40	Drip tray / baking tray
		YES	1 – 4	180 – 190	30 – 40	Shelf 4: oven tray on wire shelf Shelf 1: drip tray / baking tray
Meringues		YES	3	90	110 – 150	Drip tray / baking tray
		YES	1 – 4	90	130 – 150	Shelf 4: oven tray on wire shelf Shelf 1: drip tray / baking tray
Bread/pizza/focaccia		YES	1 / 2	190 – 250	15 – 50	Drip tray / baking tray
		YES	1 – 4	190 – 250	20 – 50	Shelf 4: oven tray on wire shelf Shelf 1: drip tray / baking tray
Bread		YES	2	180 – 220	30 – 50	Drip-tray / baking tray or wire shelf
Pizza		YES	2	220 – 250	15 – 30	Drip-tray / baking tray
Frozen pizza		YES	3	250	10 – 15	Shelf 3: drip tray / baking tray or wire shelf
		YES	1 – 4	250	10 – 20	Shelf 4: oven tray on wire shelf Shelf 1: drip tray / baking tray
Savoury pies (vegetable pie, quiche lorraine)		YES	2 – 3	180 – 190	40 – 55	Cake tin on wire shelf
		YES	1 – 4	180 – 190	45 – 60	Shelf 4: cake tin on wire shelf Shelf 1: cake tin on wire shelf
Vol-au-vents/puff pastry crackers		YES	3	190 – 200	20 – 30	Drip tray / baking tray
		YES	1 – 4	180 – 190	20 – 40	Shelf 4: oven tray on wire shelf Shelf 1: drip tray / baking tray
Lasagne/pasta bakes/cannelloni/flans		YES	3	190 – 200	45 – 65	Drip tray or oven tray on wire shelf
Lamb/veal/beef/pork, 1 kg		YES	3	190 – 200	80 – 110	Drip tray or oven tray on wire shelf

Cooking table

Recipe	Function	Pre-heating	Shelf (from bottom)	Temperature (°C)	Time (mins)	Accessories
Chicken/rabbit/duck 1 kg		YES	3	200 – 230	50 – 100	Drip tray or oven tray on wire shelf
Turkey/goose 3 kg		YES	2	190 – 200	80 – 130	Drip tray or oven tray on wire shelf
Baked fish / en papillote (fillet, whole)		YES	3	180 – 200	40 – 60	Drip tray or oven tray on wire shelf
Stuffed vegetables (tomatoes, courgettes, aubergines)		YES	2	180 – 200	50 – 60	Oven tray on wire shelf
Toast		-	5	3 (High)	3 – 6	Wire shelf
Fish fillets / steaks		-	4	2 (medium)	20 – 30	Shelf 4: wire shelf (turn food halfway through cooking)
						Shelf 3: drip tray with water
Sausages/ kebabs/spare ribs/hamburgers		-	5	2 - 3 (medium-high)	15 – 30	Shelf 5: wire shelf (turn food halfway through cooking)
						Shelf 4: drip tray with water
Roast chicken 1-1.3 kg		-	2	2 (medium)	55 – 70	Shelf 2: wire shelf (turn food two thirds of the way through cooking)
						Shelf 1: drip tray with water
				3 (High)	60 – 80	Shelf 2: turnspit (if present) Shelf 1: drip tray with water
Roast beef, rare, 1 kg		-	3	2 (medium)	35 – 50	Oven tray on wire shelf (turn food two thirds of the way through cooking if necessary)
Leg of lamb/ shanks		-	3	2 (medium)	60 – 90	Drip tray or oven tray on wire shelf (turn food two thirds of the way through cooking if necessary)
Roast potatoes		-	3	2 (medium)	35 – 55	Drip-tray / baking tray (if necessary, turn food two thirds of the way through cooking)
Vegetable gratin		-	3	3 (High)	10 – 25	Drip tray or oven tray on wire shelf
Lasagne and meat		YES	1 – 4	200	50 – 100*	Shelf 4: oven tray on wire shelf
						Shelf 1: drip tray or oven tray on wire shelf
Meat & potatoes		YES	1 – 4	200	45 – 100*	Shelf 4: oven tray on wire shelf
						Shelf 1: drip tray or oven tray on wire shelf
Fish & vegetables		YES	1 – 4	180	30 – 50*	Shelf 4: oven tray on wire shelf
						Shelf 1: drip tray or oven tray on wire shelf
Filled roast meats	 ECO	-	3	200	80 – 120*	Drip-tray or pan on rack
Meat cuts (rabbit, chicken, lamb)	 ECO	-	3	200	50 – 100*	Drip-tray or pan on rack

* Cooking time is approximate. Food can be removed from the oven at different times depending on personal preference.

Tested recipes

(in compliance with IEC 60350-1:2011-12 and DIN 3360-12:07:07)

Recipe	Function	Pre-heating	Shelf (from bottom)	Temperature (°C)	Time (mins)	Accessories and notes*
IEC 60350-1:2011-12 § 7.5.2						
Shortbread		YES	3	170	15 – 25	Drip tray / baking tray
		YES	1 – 4	150	25 – 35	Shelf 4: baking tray Shelf 1: drip tray/baking tray
IEC 60350-1:2011-12 § 7.5.3						
Small cakes		YES	3	170	20 – 30	Drip tray / baking tray
		YES	1 – 4	160	25 – 35	Shelf 4: baking tray Shelf 1: drip tray/baking tray
IEC 60350-1:2011-12 § 7.6.1						
Fat-free sponge cake		YES	2	170	30 – 40	Cake tin on wire shelf
		YES	1 – 4	160	35 – 45	Shelf 4: cake tin on wire shelf Shelf 1: cake tin on wire shelf
IEC 60350-1:2011-12 § 7.6.2						
2 apple pies		YES	2/3	185	70 – 90	Cake tin on wire shelf
		YES	1 – 4	175	75 – 95	Shelf 4: cake tin on wire shelf Shelf 1: cake tin on wire shelf
IEC 60350-1:2011-12 § 9.2						
Toast**		-	5	3 (High)	3 – 6	Wire shelf
IEC 60350-1:2011-12 § 9.3						
Burgers**		-	5	3 (High)	18 – 30	Shelf 5: wire shelf (turn food halfway through cooking)
						Shelf 4: drip tray with water
DIN 3360-12:07 § 6.5.2.3						
Apple cake, yeast tray cake		YES	3	180	30 – 40	Drip tray / baking tray
		YES	1 – 4	160	55 – 65	Shelf 4: baking tray Shelf 1: drip tray/baking tray
DIN 3360-12:07 § 6.6						
Roast pork		-	2	170	110 – 150	Shelf 2: drip-tray
DIN 3360-12:07 annex C						
Flat cake		YES	3	170	35 – 45	Drip tray / baking tray
		YES	1 – 4	160	40 – 50	Shelf 4: baking tray Shelf 1: drip tray/baking tray

The cooking table suggests the functions and ideal temperatures for obtaining best results with any type of recipe. For cooking with hot air on a single shelf, we recommend using the second level and the same temperature as that suggested for "FORCED AIR" cooking on several shelves.

* When not provided, accessories can be purchased from the After-Sales Service.

** When grilling, it is advisable to leave 3-4 cm free from the front edge of the grill to facilitate removal.

The indications given in the table are intended without the use of the sliding runners.

Energy efficiency class (in accordance with EN 60350-1:2013-07)

Use the relevant table to carry out the tests.

Recommended use and tips

How to read the cooking table

The table indicates the best function to use for any given food, to be cooked on one or more shelves at the same time. Cooking times start from the moment food is placed in the oven, excluding pre-heating (where required). Cooking temperatures and times are purely for guidance, and will depend on the amount of food and type of accessory used. Use the lowest recommended values to begin with and, if the food is not cooked enough, then move on to higher values. Use the accessories supplied and preferably dark-coloured metal cake tins and oven trays. You can also use pans and accessories in pyrex or stoneware, but bear in mind that cooking times will be slightly longer. To obtain best results, carefully follow the advice given in the cooking table for the choice of accessories (supplied) to be placed on the various shelves.

Cooking different foods at the same time

Using the "FORCED AIR" function, you can cook different foods which require the same cooking temperature at the same time (e.g.: fish and vegetables), using different shelves. Remove the food which requires less cooking time and leave food which requires longer cooking time in the oven.

Desserts

- Cook delicate desserts with the conventional function on one shelf only. Use dark-coloured metal cake tins and always position them on the wire shelf supplied. To cook on more than one shelf, select the forced air function and stagger the position of the cake tins on the shelves, aiding optimum circulation of the hot air.
- To check whether a cake is cooked, insert a wooden toothpick into the centre of the cake. If the toothpick comes out clean, the cake is ready.
- If using non-stick cake tins, do not butter the edges as the cake may not rise evenly around the edges.
- If the cake "sinks" during cooking, set a lower temperature the next time, perhaps reducing the amount of liquid in the mixture and mixing more gently.
- For sweets with moist fillings (cheesecake or fruit pies) use the "CONVECTION BAKE" function. If the base of the cake is soggy, lower the shelf and sprinkle the bottom of the cake with breadcrumbs or biscuit crumbs before adding the filling.

Meat

- Use any kind of oven tray or Pyrex dish suited to the size of the piece of meat being cooked. For roast joints, it is best to add some stock to the bottom of the dish, basting the meat during cooking for added flavour. When the roast is ready, let it rest in the oven for another 10-15 minutes, or wrap it in aluminium foil.
- When you want to grill meat, choose cuts with an even thickness all over in order to achieve uniform cooking results. Very thick pieces of meat require longer cooking times. To prevent the meat from burning on the outside, lower the position of the wire shelf, keeping the food farther away from the grill. Turn the meat two thirds of the way through cooking.

To collect the cooking juices, it is advisable to place a drip-tray with half a litre of water directly under the rack on which the meat is placed. Top-up when necessary.

Rotisserie (only on certain models)

Use this accessory to evenly roast large pieces of meat and poultry. Place the meat on the turnspit rod, tie it with string (if cooking a chicken), and check that it is secure before inserting the rod in the seat located on the front wall of the oven and resting it on the support. To prevent smoke and to collect cooking juices, it is advisable to place a drip-tray with half a litre of water on the first level. The rod has a plastic handle which must be removed before starting to cook, and used at the end of cooking to avoid burns when taking the food out of the oven.

Pizza

Lightly grease the trays to ensure the pizza has a crispy base. Scatter the mozzarella over the pizza two thirds of the way through cooking.

Rising function (only in certain models)

It is always best to cover the dough with a damp cloth before placing it in the oven. Dough proving time with this function is reduced by approximately one third compared to proving at room temperature (20-25 °C). Proving time for a 1 kg batch of pizza dough is around one hour.



FOR THE WAY IT'S MADE.

WHIRLPOOL EUROPE s.r.l. Socio Unico

Viale G. Borghi, 27
21025 COMERIO (Varese) ITALY

Phone +39 0332 759111 – Fax +39 0332 759268

www.whirlpool.eu

Printed in Italy
06/16



400010886984

