

Ⓒ For correct and safe installation of the appliance, please carefully read this manual and the other documentation provided (see section "Precautions and general advice").


**Specifications, technical data, images and parts supplied may be subject to change without prior notice.**

### ELECTRICAL CONNECTION

Connect the appliance to the mains power supply. Electrical safety of the appliance can only be guaranteed if it is correctly connected to an efficient, approved earthing system.

### POSITIONING AND LEVELLING YOUR REFRIGERATOR


If the appliance seems unsteady or you want the doors to close more easily, adjust the appliance's tilt following the instructions below (depending on the model, as shown in the figures on the right).



The refrigerator has two front and two rear wheels at the base of the product on each side and two adjustable feet at the front (see **figure A**).

1. Check the installation location to be sure you have at least 1 cm clearance on all sides including the top.
2. Connect the appliance to the mains power supply.
3. Move the refrigerator into its final position.

4. Open both doors and remove the plinth to locate the feet and levelling bolts at the left and right of the refrigerator base (where present). The top bolt (1) will adjust the rear wheel (if provided), and the bottom bolt (2) will adjust the front wheel (see **figure B**).



5. Use the wrench provided (if present) to adjust the levelling bolts. Turn clockwise to raise the appliance, or anticlockwise to lower it. It may take several turns of the levelling bolts and/or feet to adjust the tilt of the refrigerator.

6. After levelling the product, ensure that both feet touch the ground for safe use.

**Note: do not unscrew the levelling bolts and feet too much as they could fall out.**

### Aligning the doors

If, after switching on the appliance and adjusting the refrigerator and freezer doors, the doors are misaligned, disconnect the appliance from the power supply and adjust both doors as indicated in the diagram at the end of this manual.

- REMOVING THE FREEZER DOOR (A)
- REMOVING THE REFRIGERATOR DOOR (B)
- MOUNTING THE FREEZER DOOR (C)
- MOUNTING THE REFRIGERATOR DOOR (D)
- HORIZONTAL ALIGNMENT OF FREEZER AND REFRIGERATOR DOORS (E)
- VERTICAL ALIGNMENT OF FREEZER AND REFRIGERATOR DOORS (F)







